


7. Disassembly and Assembly Instructions

7-1. Disassembly

1



1) Disjoint REAR DECO.

*** Caution**

1. Take care so that do not scratch on the REAR DECO.

2



1) Unscrew 5 points.

*** Caution**

1. Unscrew 5 points to detach REAR.

3



1) Detach REAR.

*** Caution**

1. Pull upper side of REAR to detach it.

4




1) Disjoint PBA..

*** Caution**


1. While checking the attachments, detach PBA carefully from set.
2. Do not force too much on Intenna and screw hole close to vibration motor.

5



- 1) Remove connector gasket tape.
 ※ **Caution**
 1. Remove connector gasket tape carefully.
 2. Slight damage on SLIDE FPCB is not permitted.

6



- 1) Disjoint FRONT screws.

7



- 1) Separate FRONT from LCD ASS'Y.
 ※ **Caution**
 1. Down the FRONT and detach it.

8



- 1) Disjoint LOWER screw.

9



1) Separate LOWER.

※ **Caution**

1. Lift bottom of LOWER about 1cm and stir slightly.
2. Detach the LOWER while SLIDE FPCB damaged.

10




1) Remove black tape.

※ **Caution**

1. Remove the black tape carefully.

11




1) Disjoint TOUCH KEY FPCB.

※ **Caution**

1. Open the connector and disjoint TOUCH KEY FPCB.

12




1) Disjoint camera part.

※ **Caution**

1. Disjoint the CAMERA FPCB.
2. Disjoint speaker and CIF camera.

13



- 1) Disjoint SUB LCD HOOK.
- ※ **Caution**
- 1. Lean LOWER BOTTOM to window side to disjoint it from LCD ASS'Y.

14



- 1) Separate LCD.
- ※ **Caution**
- 1. Lift the upside of LCD first and lift LCD PBA next.
- 2. Because the FPCB between LCD and LCD PBA are easy to be torn, lift the LCD PBA with care.

7-2. Assembly

1




1) Put the main LCD in window frame.

※ **Caution**

1. First, put the main LCD part in window frame.
Main LCD consists of display part and PBA part.
Red dashed lines point to display part.

2




1) Put the lower bottom to right position.

※ **Caution**

1. Insert lower bottom to LCD ASS'Y.
2. First, match window side then lean toward PBA side.
3. Lean the lower bottom until it sound undertone.

3




1) Assemble touch key FPCB to connector.

※ **Caution**

1. Assemble touch key FPCB to connector (dashed line).
2. Locate connector so that white silk lines aligned.

4




1) Combine camera.

※ **Caution**

1. Connect camera FPCB to connector(dashed line).
2. Keep white silk line aligned.
3. Assemble by CIF camera/speaker/5MEGA camera order.

5




- 1) Attach black tape like picture below.
 ※ **Caution**
 1. Make sure not to cross over base line above.
 2. Attach black tape like that way.

6



- 1) Combine LOWER.
 ※ **Caution**
 1. Insert FPCB between LOWER hole.
 2. Combine top position HOOK and lower position screw assembly part.

7




- 1) Contract LOWER screw.
 ※ **Caution**
 1. Confirm screw size. (1.4* 2.5mm)
 2. Screw after dashed positions are matched.

8




- 1) Assemble FRONT.
 ※ **Caution**
 1. Insert SLIDE FPCB to dashed insertion hole like upper picture.
 2. Insert FRONT lower RIB under hinge and match the six screw joint positions.

9




- 1) Screw six point to fix FRONT to LCD ASS'Y.
※ Caution
 1. Confirm screw size. (1.4* 2.5mm)
 2. Screw 6 points.

10




- 1) Combine PBA.
※ Caution
 1. When slide is closed, combine connector to PBA.
 2. Fold SLIDE FPCB connector like image.

11



- 1) Attach connector gasket tape.
※ Caution
 1. Place the connector gasket tape aligned like picture.

12



- 1) Put PBA.
※ Caution
 1. Open slide and place the PBA.
 2. Combine left side HOOK.
 3. Place the Vibration motor in PBA hole.

13



- 1) Combine REAR COVER.
 ※ **Caution**
 1. Combine both side HOOK from bottom.

14



- 1) Screw REAR COVER.
 ※ **Caution**
 1. Confirm screw size.(1.4* 3.5mm)
 2. Screw 5 points.