


5. Exploded View and Parts List

5-1. Cellular phone Exploded View



5-2. Cellular phone Parts list

| Design LOC | Description | SEC CODE |
|------------|-----------------------------|-------------|
| QAN02 | INTENNA-SGHZ620 | GH42-00849A |
| QBA00 | ASSY COVER-BATT | GH98-02985A |
| QBA01 | INNER BATTERY PACK-900MAH | GH43-02398A |
| QBR09 | NDC-HINGE BRACKET | GH71-06431A |
| QCA01 | UNIT-CAMERA | GH59-03288A |
| QCR06 | SCREW-MACHINE | 6001-001155 |
| QCR47 | SCREW-MACHINE | 6001-001695 |
| QCR49 | SCREW-MACHINE | 6001-001823 |
| QFR01 | ASSY CASE-FRONT | GH98-02959A |
| QFU01 | ASSY CASE-F/UPPER | GH98-02791A |
| QKP01 | ASSY KEYPAD-(TIM/BLK) | GH98-02790A |
| QMI01 | MICROPHONE-ASSY-SGHD830 | GH30-00278A |
| QMI03 | RMO-RUBBER MIC HOLDER | GH73-07110A |
| QMO01 | MOTOR DC-SGHZ620 | GH31-00265A |
| QMP01 | PBA MAIN-SGHZ620 | GH92-02732A |
| QRF01 | PMO-RUBBER RF COVER | GH72-30630A |
| QSC05 | MPR-FOLDER SCREW SHEET A | GH74-22971A |
| QSC06 | MPR-FOLDER SCREW SHEET B | GH74-22972A |
| QSC13 | RMO-RUBBER REAR SCREW COVER | GH73-07752A |
| QSC16 | MPR-TAPE F/TOP SCREW A | GH74-27733A |
| QSC18 | MPR-TAPE F/TOP SCREW B | GH74-27734A |
| QSP01 | SPEAKER | 3001-002015 |
| QVK01 | UNIT-VOLUME KEY | GH59-03219A |
| QRE01 | ASSY-CASE-REAR | GH98-00901A |
| QIF01 | PMO-COVER IF | GH72-30626A |
| QSD01 | PMO-COVER MICRO SD | GH72-30628A |
| QVO01 | PMO-VOLUME KEY | GH72-30629A |
| QFL01 | ASSY-CASE-F/LOWER | GH98-00898A |
| QHI01 | ASSY-HINGE | GH98-00899A |
| QLC01 | MEA-LCD MODULE KIT | GH97-06596A |
| QMW01 | AS-LCD WINDOW | GH81-04515A |

| Discription | SEC CODE |
|-------------------------------|-------------|
| BAG PE | 6902-000297 |
| CBF INTERFACE-DATA LINK CABLE | GH39-00444A |
| ADAPTOR-SGHD800 TA(EU) | GH44-01060A |
| S/W CD-SGHZ620 PC STUDIO 3.0 | GH46-00328A |
| UNIT-EARPHONE(BLK) | GH59-02499A |
| LABEL(P)-WATER SOAK | GH68-02026A |
| LABEL(P)-WATER SOAK | GH68-02026A |
| LABEL(R)-MASTER TIM | GH68-11408B |
| MANUAL USERS-TIM TALIAN | GH68-11875A |
| LABEL(P)-BASE FRONT LABEL | GH68-12049A |
| LABEL(R)-MAIN(TIM) | GH68-12061A |
| BOX(P)-UNIT MAIN(TIM) | GH69-04317A |
| CUSHION-CASE TA2 MA2 | GH69-04584A |
| RMO-RUBBER YAMAHA | GH73-07659A |
| MPR-BOHO VINYL LCD CONN | GH74-15350A |
| MPR-VINYL BOHO F/UPPER B | GH74-25093A |
| MPR-VINYL BOHO MAIN WIN A | GH74-25095A |
| MPR-TAPE DUST PREVENTION | GH74-25103A |
| MPR-TAPE KEY TAIL | GH74-25104A |
| MPR-GASK TAPE | GH74-25105A |
| MPR-TAPE GASKET IF | GH74-25107A |
| MPR-TAPE ESD LCD MODULE | GH74-25846A |
| MPR-INSU TAPE PBA VOLKEY | GH74-26674A |
| MPR-INSU TAPE PBA SD | GH74-27338A |
| MPR-INSU TAPE PBA IF | GH74-27375A |
| MPR-TAPE | GH74-27595A |
| MPR-TAPE | GH74-27596A |
| MPR-TAPE KEYPAD PREVENTION | GH74-27820A |
| MPR-VINYL BOHO STATIC | GH74-28052B |
| MPR-TAPE KEYPAD R | GH74-28054A |
| AS-LCD TAPE | GH81-05256A |
| AS-IC-MCP UMTS | GH81-05912A |


5-3. Disassembly

1




- 1) Remove 6Screws on Rear Case.
 - 2) Open the IF COVER.
 - 3) Open the MICRO SD COVER.
- * caution**
- 1) Be careful not to get a damage.

2




- 1) Lift the hook at the end of the lower case with an instrument and disassemble the Rear Cover like the sequence below.
- * caution**
- 1) Be careful not to get a damage of Rear Case.

3



- 1) Detach the LCD,CAMERA conn.
 - 2) Detach the Vol Key FPCB with tweezers
 - 3) Remove the screw on PBA.
 - 4) Remove the Keypad.
- * caution**
- 1) Be careful not to get a damage of FPCB when Detaching LCD conn, CAM conn, and VOLUME KEY FPCB.

4



- 1) Remove the dust prevention tape.
- * caution**
- 1) Pay attention to damage of the LCD,CAM conn.

5




- 1) Disassemble the Front Cover from front case by Pushing out the hinge spring.
- 2) Please refer to the Picture below.

*** caution**

- 1) Be careful not to get a damage.
- 2) Pay attention to the damage of the LCD,CAM conn.

6



- 1) Remove the SCREW CAP.
- 2) UNSCREW 4 Points.

*** caution**

- 1) When you use a screwdriver, Be careful of the damage of component.

7



- 1) Disassemble the Upper Case of the folder with an instrument like below.

*** caution**

- 1) Be careful not to get a damage.

8




- 1) Separate the MOT & SPK with tweezers.
- 2) Remove the LCD from the LOWER case (Holding the direction of hinge bracket like below)

*** caution**

- 1) When you remove the LCD. Be careful of the crack and damage of the LCD & LCD FPCB

9



- 1) Remove the Hinge Bracket with tweezers.
- 2) In order to detach the CAM, Remove the Hinge like below

*** caution**

- 1) Be careful of the crack and damage of the CAM FPCB


10



- 1) Please check the disassembled part.

5-4. Assembly

1




- 1) Insert CAM FPCB in the LOWER like below.
 - 2) Insert Hinge like below Please refer to the Picture below.
- * caution**
- 1) Be careful CAM FPCB Crack.

2



- 1) Insert LCD FPCB keeping up the lower direction of Hinge Bracket
 - 2) Place the SPK & MOTOR.
 - 3) Place the LCD.
- * caution**
- 1) When you insert the LCD FPCB, Pay attention to damage of the FPCB
 - 2) Be careful of SPK & MOTOR wire crack

3



- 1) Combine the UPPER & Lower
Please refer to the sequence below.
- * caution**
- 1) Be careful not to get a damage of outward

4



- 1) SCREW the 4 POINTS.
- * caution**
- 1) When you use a screwdriver, Be careful of the damage of component.

5



- 1) Combine the Folder and Front case like the picture below.(Keeping up the lower direction of hinge bracket and Folder position.)

* caution

- 1) Be careful not to get a damage.
- 2) Be careful of the crack and damage of LCD, LCD Conn.
- 3) Absolutely Keep up the picture's direction of Folder

6



- 1) Keeping up the FOLDER's direction, Combine the Folder with a instrument.

* caution

- 1) Be careful not to get a damage.
- 2) Absolutely Keep up the picture's direction of Folder

7



- 1) Combine the KEY FPCB Conn.

* caution

- 1) Be careful not to get a damage of KEY FPCB

8



- 1) Screw down

- 2) Connect CAMERA,LCD Conn.and VOLUME KEY FPCB

* caution

- 1) Be careful not to get a damage of CAMERA,LCD FPCB and VOLUME KEY FPCB.

9



10



- 1) Assemble the REAR with FRONT ASS'Y like below sequence.



*** caution**

- 1) Be careful not to get a damage.


- 1) SCREW the 6 POINTs.
 2) Insert SCREW Cap at two points
*** caution**
 2) Pay attention to damage of the LCD con FPCB.

5-5. LCD KIT

1



2



1) Attach the gasket on the LCD Conn.

* **caution**

1) Attach the gasket according to red line like a picture.

1) Attach the black insulation tape on the LCD

* **caution**

1) Be careful of the red lines.