Aspire 6920 Series Service Guide

Service guide files and updates are available on the ACER/CSD web; for more information, please refer to http://csd.acer.com.tw

PRINTED IN TAIWAN

Revision History

Please refer to the table below for the updates made on Aspire6920 service guide.

Date	Chapter	Updates

Copyright

Copyright © 2008 by Acer Incorporated. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Acer Incorporated.

Disclaimer

The information in this guide is subject to change without notice.

Acer Incorporated makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties of merchantability or fitness for any particular purpose. Any Acer Incorporated software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not Acer Incorporated, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software.

Acer is a registered trademark of Acer Corporation. Intel is a registered trademark of Intel Corporation.

Pentium and Pentium II/III are trademarks of Intel Corporation.

Other brand and product names are trademarks and/or registered trademarks of their respective holders.

Conventions

The following conventions are used in this manual:

SCREEN MESSAGES	Denotes actual messages that appear on screen.
NOTE	Gives bits and pieces of additional information related to the current topic.
WARNING	Alerts you to any damage that might result from doing or not doing specific actions.
CAUTION	Gives precautionary measures to avoid possible hardware or software problems.
IMPORTANT	Reminds you to do specific actions relevant to the accomplishment of procedures.

Preface

Before using this information and the product it supports, please read the following general information.

- 1. This Service Guide provides you with all technical information relating to the BASIC CONFIGURATION decided for Acer's "global" product offering. To better fit local market requirements and enhance product competitiveness, your regional office MAY have decided to extend the functionality of a machine (e.g. add-on card, modem, or extra memory capability). These LOCALIZED FEATURES will NOT be covered in this generic service guide. In such cases, please contact your regional offices or the responsible personnel/channel to provide you with further technical details.
- 2. Please note WHEN ORDERING FRU PARTS, that you should check the most up-to-date information available on your regional web or channel. If, for whatever reason, a part number change is made, it will not be noted in the printed Service Guide. For ACER-AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code to those given in the FRU list of this printed Service Guide. You MUST use the list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

System Specifications

Features

Below is a brief summary of the computer's many feature:

Operating system: Windows Vista™

NOTE: Windowsl[®] VistaTM Capable PCs come with Windows[®] XP installed, and can be upgraded to Windows[®] VistaTM. For more information on Windows[®] VistaTM and how to upgrade, go to: Microsoft.com/windowsvista.

Platform and memroy

- Intel® Centrino® Duo mobile processor technology, featuring:
- Intel® Core™2 Duo mobile processor
- Mobile Intel® GM965/PM965 Express Chipset
- Intel® Wireless WiFi Link Wi-Fi CERTIFIED® network connection
- Intel® PRO/Wireless Wi-Fi CERTIFIED® network connection.
- Dual-Channel DDR2 SDRAM support
- Up to 2 GB of DDR2 667 MHz memory, upgradeable to 4 GB using two soDIMM modules

Display and graphics

- Mobile Intel® GM965/PM965 Express Chipset (for selected models)
- NVIDIA® GeForce® 9500M GS with 512MB of dedicated VRAM supporting TurboCache™ (for selected models)

TV-tuner

Digital TV-tuner supporting DVB-T

Audio

- Dolby® -certified surround sound system with two built-in stereo speakers and one subwoofer supporting lowfrequency effects
- · S/PDIF (Sony/Philips Digital Interface) support for digital speakers
- · Built-in stereo microphones

Storage subsystem

- 2.5" hard disk drive
- · Optical drive options:
- Blu-ray Disc™ (BD) drive (for selected models)
- DVD-Super Multi double-layer drive
- 6-in-1 card reader

Input devices

- 88-/89-key keyboard
- · Touchpad pointing device
- Acer CineDash media console capacitive human interface device, including: capacitive

human interface device.

Communication

- · Acer Video Conference, featuring:
- Integrated Acer Crystal Eye webcam
- · Acer Video Conference Manager software
- Acer PureZone technology
- Optional Acer Xpress VoIP phone
- WLAN: Intel® Wireless WiFi Link network connection or Intel® PRO/Wireless network connection
- WPAN: Bluetooth® 2.0+EDR
- LAN: Gigabit Ethernet, Wake-on-LAN ready
- Modem: 56K ITU V.92

I/O Ports

- ExpressCard™/54 slot
- 6-in-1 card reader (SD™, MMC, MMCplus™, MS, MS PRO, xD)
- Four USB 2.0 ports
- HDMI[™] port with HDCP support (for selected models)
- · Consumer infrared (CIR) port
- External display (VGA) port
- · Headphone/speaker/line-out jack with S/PDIF support
- Microphone-in jack
- Line-in jack
- Ethernet (RJ-45) port
- Modem (RJ-11) port

NOTE: • HDCP is acronym for High-bandwidth Digital Content Protection. An encryption system for enforcing digital rights management (DRM) over DVI and HDMI interfaces

Environment

• Temperature:

•operating: 5° C to 35° C


•Non-operating: -20 ° C to 65 ° C

·Humidity (non-condensing):


•operating: 20%~80%

Non-operating: 20%~80%


System Block Diagram



Board Layout



Aspi	Aspire6920 M/B layout and connector location TOP view				
No.	Name	Description			
1	CN1	LED/B Cable CNTR			
2	CN2	LCM Cable CNTR			
3	CN3	Key board FFC CNTR			
4	CN4	USB board CNTR			
5	CN7	Hot Key Board CNTR			
6	U8	South Bridge			
7	CN12	Touch pad FFC CNTR			
8	CN14	I/O Board CNTR			
9	CN15	BT cable CNTR			
10	CN13	Express card CNTR			
11	CN10	Speaker cable CNTR			
12	CN9	Media consle Board CNTR			
13	CN8 Power Board FFC CNTR				



Bottom view				
No.	Name Description			
1	CN6002	W/LAN card board CNTR		
2	CN6001	TV/Robson card CNTR		
3	CN1003	USB Port		
4	CN1002	USB Port		
5	CN1005	USB Board CNTR		
6	CN501	VGA Port		
7	Jack501	RJ45		
8	CN505	USB Port		
9	CN508	HDMI Port		
10	Jack502	SPDIF		
11	Jack503	MIC jack		
12	Jack504	Line in jack		
13	CN516	MDC Card CNTR		
14	CN512	New card socket		
15	CN511/513	DIMM socket		
16	CN514	HDD CNTR		
17	CN515	PCI-E socket		
18	CN510	ODD CNTR		
19	U517	North Bridge		
20	CN507	CPU Socket		
21	CN506	VGA Card Socket		

Your Acer Notebook tour


After knowing your computer features, let us show you around your new Aspire computer.

Top view




#	lcon	Item	Description	
1		Acer Crystal Eye	Web camera for video communication.	
2	2 Acer PureZone		Two internal stereo microphones for sound recording.	
3		Display screen	Also called Liquid-Crystal Display (LCD), displays computer output.	
4	4 Status indicators		Light-Emitting Diodes (LEDs) that light up to show the status of the computer's functions and components.	
5		Power button	Turns the computer on and off.	
6		CineDash media console	The CineDash media console is a touch- sensitive entertainment interface.	
7 Keyboard For entering da		Keyboard	For entering data into your computer.	
8 Palmrest		Palmrest	Comfortable support area for your hands when you use the computer.	
9		Touchpad	Touch-sensitive pointing device which functions like a computer mouse.	
10		Click buttons (left, center* and right)	The left and right buttons function like the left and right mouse buttons. *The center button serves as Acer Bio-Protection fingerprint reader supporting Acer FingerNav 4-way control function (for selected models).	
11	11 Status indicators		Light-Emitting Diodes (LEDs) that light up to show the status of the computer's functions and components.	
12		Easy-launch button	Buttons for launching frequently used program.	
13		Speakers	5.1 speakers deliver stereo audio output.	
14	e	Empowering key	Lanuch Acer Empowering Technology	

Closed Front View



Left View



#	lcon	Item	Description	
1		DC-in jack	Connects to an AC adapter.	
2		Modem (RJ-11) port	Connects to a phone line.	
3		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).	
4	용	Ethernet (RJ-45) port	Connects to an Ethernet 10/100-based network.	
5	● ✓•+	USB 2.0 port	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).	
6	HDMI	HDMI port Supports high definition digital video connections (for selected models).		
7	SPDIF	Headphones/ speaker/line-out jack with S/PDIF support	Connects to audio line-out devices (e.g., speakers, headphones).	
8	100	Microphone-in jack	Accepts input from external microphones.	
9	(+)	Line-in jack	Accepts audio line-in devices (e.g., audio CD player, stereo walkman).	
10	ExpressCard / 54	ExpressCard/54 slot	Accepts one ExpressCard/54 module.	

Right View

Right view



#	lcon	Item Description		
1		Optical drive	Internal optical drive; accepts CDs or DVDs.	
2	Optical disk access Lights up when the optical d indicator active.		Lights up when the optical drive is active.	
3 Optical drive eject Ejects the optical dis button		Ejects the optical disk from the drive.		
4		Emergency eject hole	Ejects the optical drive tray when the computer is turned off.	
5			Connect to USB 2.0 devices (e.g., USB mouse, USB camera).	
6	户	TV-in port	Accepts input signals from analog/digital TV-tuner devices (for selected models).	
7	Δ		Connects to a Kensington-compatible computer security lock.	
7 Kensington lock slot		Kensington lock slot	Connects to a Kensington-compatible computer security lock.	


Rear view



#	Item	Description
1	Tuba	The dedicated Tuba CineBass subwoofer pumps out earthshaking movie-house audio.
2	Ventilation slots	Enable the computer to stay cool, even after prolonged use.

Base view





#	Icon	Item	Description
1		Memory compartment	Houses the computer's main memory.
2		Hard disk bay	Houses the computer's hard disk (secured with screws).
3		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use.
			Note : Do not cover or obstruct the opening of the fan.
4	<u> </u>	Battery bay	Houses the computer's battery pack.
5		Battery release latch	Releases the battery for removal.
6		Battery lock	Locks the battery in position.

Indicators

The computer has several easy-to-read status indicators.



The front panel indicators are visible even when the computer cover is closed up.

Icon	Function	Description
*	HDD	Indicates when the hard disk drive is active.
1	Num Lock	Lights up when Num Lock is activated.
Ā	Caps Lock	Lights up when Caps Lock is activated.
`	Power	Indicates the computer's power status.
Ē	Battery	Indicates the computer's batttery status.

NOTE: 1. **Charging:** The light shows amber when the battery is charging. 2. **Fully charged:** The light shows green when in AC mode.

Easy-Launch Buttons

Located beside the keyboard are application buttons. These buttons are called easy-launch buttons. They are: WLAN, Internet, email, Bluetooth and Acer Empowering Technology.

The mail and Web browser buttons are pre-set to email and Internet programs, but can be reset by users. To set the Web browser, mail and programmable buttons, run the Acer Launch Manager.



Icon	Function	Description	
Empowering Technology		Launch Acer Empowering Technology. (user-programmable)	
<i>C</i>	Wireless communication button/indicator	Enables/disables the wireless function. Indicates the status of wireless LAN communication.	
Web browser		Internet browser (user-Programmable)	
Mail		Email application (user-Programmable)	
*	Bluetooth communication button/ indicator	Enables/disables the Bluetooth function. Indicates the status of Bluetooth communication.	

Touchpad Basics

The following teaches you how to use the touchpad:



Move your finger across the touchpad (2) to move the cursor.

Press the left (1) and right (4) buttons located beneath the touchpad to perform selection and execution functions. These two buttons are similar to the left and right buttons on a mouse. Tapping on the touchpad is the same as clicking the left button.

Use the 4-way scroll (3) button to scroll up or down and move left or right a page. This button mimics your cursor pressing on the right scroll bar of Windows applications.

Function	Left button (1)	Right button (4)	Main touchpad (2)	Center button (3)
Execute	Quickly click twice.		Tap twice (at the same speed as double-clicking a mouse button).	
Select	Click once.		Tap once.	
Drag	Click and hold, then use finger on the touchpad to drag the cursor.		Tap twice (at the same speed as double-clicking a mouse button); rest your finger on the touchpad on the second tap and drag the cursor.	
Access context menu		Click once.		
Scroll				Swipe up/down/left/ right using Acer FingerNav 4-way control function (for selected models) or click and hold to move up/down/left/ right (for selected models).

NOTE: When using the touchpad, keep it - and your infers - dry and clean. The touchpad is sensitive to finger movements; hence, the lighter the touch, the better the response. Tapping too hard will not increase the touchpad's responsiveness.

Using the Keyboard

The keyboard has full-sized keys and an embedded keypad, separate cursor keys, two Windows keys and twelve function keys.

Lock Keys and embedded numeric keypad

The keyboard has three lock keys which you can toggle on and off.



Lock key	Description
Caps Lock	When Caps Lock is on, all alphabetic characters typed are in uppercase.
Num Lock < Fn> + <f11></f11>	When Num Lock is on, the embedded keypad is in numeric mode. The keys function as a calculator (complete with the arithmetic operators +, -, *, and /). Use this mode when you need to do a lot of numeric data entry. A better solution would be to connect an external keypad.
Scroll Lock <fn> + <f12></f12></fn>	When Scroll Lock is on, the screen moves one line up or down when you press the up or down arrow keys respectively. Scroll Lock does not work with some applications.

The embedded numeric keypad functions like a desktop numeric keypad. It is indicated by small characters located on the upper right corner of the keycaps. To simplify the keyboard legend, cursor-control key symbols are not printed on the keys.

Desired access	Num Lock on	Num Lock off
Number keys on embedded keypad	Type numbers in a normal manner.	
Cursor-control keys on embedded keypad	Hold <shift></shift> while using cursor-control keys.	Hold <fn></fn> while using cursor-control keys.
Main keyboard keys	Hold <fn> while typing letters on embedded keypad.</fn>	Type the letters in a normal manner.

The embedded numeric keypad functions like a desktop numeric keypad. It is indicated by small characters located on the upper right corner of the keycaps. To simplify the keyboard legend, cursor-control key symbols are not printed on the keys.

Desired Access	Num Lock On	Num Lock Off
Number keys on embedded keypad	Type numbers in a normal manner.	
Cursor-control keys on embedded keypad	Hold <shift> while using cursor-control keys.</shift>	Hold <fn> while using cursor-control keys.</fn>
Main keyboard keys	Hold <fn> while typing letters on embedded keypad.</fn>	Type the letters in a normal manner.

Windows Keys

The keyboard has two keys that perform Windows-specific functions.

Key		Description
	Windows key	Pressed alone, this key has the same effect as clicking on the Windows Start button; it launches the Start menu. It can also be used with other keys to provide a variety of functions:
		< ☞ >: Open or close the Start menu
		< (♣)> + <d>:</d> Display the desktop
		< (♣)> + <e>:</e> Open Windows Explore
		<** > + $<$ F>: Search for a file or folder
		< >> + <g>: Cycle through Sidebar gadgets</g>
		<>> + <l>: Lock your computer (if you are connected to a network domain), or switch users (if you're not connected to a network domain)</l>
		<>> + <m>: Minimizes all windows</m>
		< $> + <$ R $>$: Open the Run dialog box
		< $> + <$ T>: Cycle through programs on the taskbar
		< $> + <$ U $>:$ Open Ease of Access Center
		< (♣)> + <x>:</x> Open Windows Mobility Center
		→ + <break>: Display the System Properties dialog box</break>
		< (♣)> + <shift+m></shift+m> : Restore minimized windows to the desktop
		<>> + <tab>: Cycle through programs on the taskbar by using Windows Flip 3-D</tab>
		<>> + <spacebar>: Bring all gadgets to the front and select Windows Sidebar</spacebar>
		<ctrl> + < >> + <f>: Search for computers (if you are on a network)</f></ctrl>
		<ctrl> + < > > + <tab>: Use the arrow keys to cycle through programs on the taskbar by using Windows Flip 3-D</tab></ctrl>
		(2)
		Note : Depending on your edition of Windows Vista, some shortcuts may not function as described.
	Application key	This key has the same effect as clicking the right mouse button; it opens the application's context menu.

Hot Keys

brightness, volume output and the BIOS utility.

t KeysThe computer employs hotkeys or key combinations to access most of the computer's controls like sreen

To activate hot keys, press and hold the **<Fn>** key before pressing the other key in the hotkey combination.



Hotkey	lcon	Function	Description
<fn> + <f1></f1></fn>	?	Hotkey help	Displays help on hotkeys.
<fn> + <f2></f2></fn>	©	Acer eSettings	Launches Acer eSettings in Acer Empowering Technology.
<fn> + <f3></f3></fn>	&	Acer ePower Management	Launches Acer ePower Management in Acer Empowering Technology. See
<fn> + <f4></f4></fn>	Z ^z	Sleep	Puts the computer in Sleep mode.
<fn> + <f5></f5></fn>		Display toggle	Switches display output between the display screen, external monitor (if connected) and both.
<fn> + <f6></f6></fn>		Screen blank	Turns the display screen backlight off to save power. Press any key to return.
<fn> + <f7></f7></fn>		Touchpad toggle	Turns the internal touchpad on and off.
<fn> + <f8></f8></fn>	□(/■ »	Speaker toggle	Turns the speakers on and off.
<fn> + <→></fn>	Ö	Brightness up	Increases the screen brightness.
<fn> + <←></fn>	.	Brightness down	Decreases the screen brightness.

Special Key

You can locate the Euro symbol and US dollar sign at the upper-center and/or bottom-right of your keyboard. To type:



The Euro symbol

- 1. Open a text editor or word processor.
- 2. Either directly press the < € > symbol at the bottom-right of the keyboard, or hold <Alt Gr> and then press the <5> symbol at the upper-center of the keyboard.

NOTE: Some fonts and software do not support the Euro symbol. Please refer to www.microsoft.com/typography/faq/faq12.htm for more information.

The US dollar sign

- 1. Open a text editor or word processor.
- 2. Either directly press the < \$> key at the bottom-right of the keyboard, or hold <Shift> and then press the <4> key at the upper-center of the keyboard.

NOTE: This function varies by the operating system version.

Acer Empowering Technology

Acer's innovative Empowering Technology makes it easy for you to access frequently used functions and manage your new Acer notebook. It features the following handy utilities:

- Acer eAudio Management allows you to easily control the enhanced sound effects of Dolby Home Theater on your system.
- Acer ePower Management optimizes battery usage via customizable power plans.
- Acer eDataSecurity Management protects data with passwords and encryption (for selected models).
- Acer eRecovery Management backs up and recovers data flexibly, reliablyand completely.
- Acer eSettings Management accesses system information and adjusts settings easily.



For more information, press the < < < < key to launch the Empowering Technology menu, then click on the appropriate utility and select the Help or Tutorial function.

Empowering Technology password

You must set the Empowering Technology password to use the password protection feature of Acer eRecovery Management to protect your data.

To set the Empowering Technology password:

- 1 Launch Acer eRecovery Management.
- 2 Click the Restore tab.
- 3 Click Password settings. The Empowering Technology Password Center dialog box pops up.
- 4 Click Create a new password.



5 In the Create a New Password dialog box, key in and confirm your password in the appropriate boxes.

Your password should have a minimum of 4 and a maximum of 12 characters.

6 Enter a password hint that will help you remember your password.

7 Make sure the box Use for Acer eRecovery Management is checked. 8 Click OK to set the password.



Acer eAudio Management

Acer eAudio Management allows you to easily control the enhanced sound effects of Dolby Home Theater on your system. Select Movie or Game mode to experience the awesome realism of 5.1-channel audio output from the speakers fitted to your system via Dolby Surround sound technology. Music mode lets you enjoy your favorite tunes, in vivid detail.



To choose your playback device, click the icon on the upper right side of the Acer eAudio Management window.



Acer ePower Management



Acer ePower Management features a straightforward user interface for configuring your power management options. To access this utility, select Acer ePower Management from the Empowering Technology toolbar, run the program from the Acer Empowering Technology program group in Start menu, or right-click the Windows power icon in the system tray and select Acer ePower Management.

AC Mode (Adapter mode)

The default setting is "Maximum Performance." You can adjust CPU speed, LCD brightness and other settings, or click on buttons to turn the following functions on/off: Wireless LAN, Bluetooth, CardBus, FireWire (1394), Wired LAN and Optical Device if supported.

DC Mode (Battery mode)

There are four pre-defined profiles - Entertainment, Presentation, Word Processing, and Battery Life. You can also define up to three of your own.

To create new power profile

- 1. Change power settings as desired.
- 2. Click "Save as..." to save to a new power profile.
- 3. Name the newly created profile.
- 4. Select whether this profile is for Adapter or Battery mode, then click OK.
- 5. The new profile will appear in the profile list.

Battery status

For real-time battery life estimates based on current usage, referto the panel on the lower left-hand side of the window.



For additional options, click "Settings" to:

Set alarms.

Re-load factory defaults.

Select what actions will be taken when the cover is closed or the power button is pressed.


View information about Acer ePower Management.

Acer eDataSecurity Management

(for selected models)

Acer eDataSecurity Management is an encryption utility that protects your files from being accessed by unauthorized persons. It is conveniently integrated with Windows Explorer as a shell extension for quick data encryption/decryption and also supports on-the-fly file encryption for Lotus Notes and Microsoft Outlook. On first use, the Acer eDataSecurity Management setup wizard will prompt you to create the Master Password. You will use this password to access the Personal Secure Disk (PSD). The Master Password may also be used to encrypt/decrypt files by default.

If you set a different password to encrypt a file, but you forgot the encryption password, you can use the Master Password to decrypt the file.






Acer eRecovery Management

Acer eRecovery Management is a versatile backup utility. It allows you to create full or incremental backups, burn the factory default image to optical disc, and restore from previously created backups or reinstall applications and drivers. By default, user-created backups are stored to the D:\ drive.

Acer eRecovery Management provides you with:

- Backup:
- Back up factory default to CD/DVD
- Back up drivers and applications to CD/DVD
- Create user backup
- Manage user backups
- · Restore:
- · Restore system to factory default
- Reinstall applications/drivers
- · Restore system from user backup
- Password settings

To use the password protection feature of Acer eRecovery Management to protect your data, you must first set the Empowering Technology password. To set the password, refer to the section "Empowering Technology password".





Acer eSettings Management


Acer eSettings Management allows you to inspect hardware specifications, set BIOS passwords and modify boot options.

Acer eSettings Management also:

- Provides a simple graphical user interface for navigation.
- Prints and saves hardware specifications.
- · Lets you set an asset tag for your system.



Windows Mobility Center



The Windows Mobility Center collects key mobile-related system settings in one easy-to-find place, so you can quickly configure your Acer system to fit the situation as you change locations, networks or activities. Settings include display brightness, volume, power plan, wireless networking on/off, external display settings, synchronization status and presentation settings.

Windows Mobility Center also includes Acer-specific settings like sharing folders overview/sharing service on or off, Bluetooth Add Device (if applicable), and a shortcut to the Acer user guide, drivers and utilities.

To launch Windows Mobility Center:

- Use the shortcut key < > + <X>.
- Start Windows Mobility Center from the Control panel.
- Start Windows Mobility Center from the Accessories program group in the Start menu.
- Launch Windows Mobility Center by right-clicking in the system tray and select Windows Mobility Center.


Using the System Utilities

NOTE: The system utilities work under Microsoft Windows XP only.

Acer GridVista (dual-display compatible)

NOTE: This feature is only available on certain models.

To enable the dual monitor feature of the notebook, first ensure that the second monitor is connected, then select **Start, Control Panel, Display** and click on **Settings**. Select the secondary monitor **(2)** icon in the display box and then click the check box **Extend my windows desktop onto this monitor**. Finally, click **Apply** to confirm the new settings and click **OK** to complete the process.



Acer GridVista is a handy utility that offers four pre-defined display settings so you can view multiple windows on the same screen. To access this function, please go to **Start>All Programs** and click on **Acer GridVista**. You may choose any one of the four display settings indicated below:




Double (verticle), Triple (primary at left), Triple (primary at right), or Quad Acer Gridvista is dual-display compatible, allowing two displays to be partitioned indepently.

Acer Gridvista is dual-display compatible, allowing two displays to be partitioned independently.


AcerGridVista is imple to set up:

- 1. Run Acer GridVista and select your preferred screen configuration for each display from the task bar.
- 2. Drag and drop each window into the appropriate grid.
- 3. Enjoy the convenience of a well-organized desktop.



NOTE: Please ensure that the resolution setting of the second monitor is set to the manufacturer's recommended value.

Launch Manager



Launch Manager allows you to set the four easy-launch buttons located above the keyboard. You can access the Launch Manager by clicking on Start > All Programs > Launch Manager to start the application.

Hardware Specifications and Configurations

Processor	
Item	Specification
CPU type	Intel CPU Penryn
Core logic	Intel 965PM/965GM + ICH8M
CPU package	uFCPGA, Socket P
CPU core voltage	0.944~1.3V

Second Level Cache	
Item	Specification
Cache controller	Built-in CPU
Cache size	6MB
1st level cache control	Always enabled
2st level cache control	Always enabled
Cache scheme control	Fixed in write-back

System Memory	
Item	Specification
Memory controller	Intel PM965 / Intel GM965
Memory size	0MB (no on-board memory)
DIMM socket number	2 sockets
Supports memory size per socket	2GB
Supports maximum memory size	4GB
Supports DIMM type	DDR 2 Synchronous DRAM
Supports DIMM Speed	533/667 MHz
Supports DIMM voltage	1.8V and 0.9V
Supports DIMM package	200-pin soDIMM

LAN Interface	
Item	Specification

Chapter 1 31

Chipset	ATHEROS_AR8121
Supports LAN protocol	10/100/1000 Ethernet
PCI-E Giga	
LAN connector type	RJ45
LAN connector location	Left side
Features	Integrated 10/100/1000 BASE-T transceiver

NOTE: Above table lists some system memory configurations. You may combine DIMMs with various capacities to form other combinations. On above table, the configuration of slot 1 and slot 2 could be reversed.

Memory Combinations		
Slot 1	Slot 2	Total Memory
0MB	256MB	256MB
0MB	512MB	512MB
0MB	1024MB	1024MB
0MB	2048MB	2048MB
256MB	256MB	512MB
256MB	512MB	768MB
256MB	1024MB	1280MB
256MB	2048MB	2304MB
512MB	256MB	768MB
512MB	512MB	1024MB
512MB	1024MB	1536MB
512MB	2048MB	2560MB
1024MB	0MB	1024MB
1024MB	256MB	1280MB
1024MB	512MB	1536MB
1024MB	1024MB	2048MB
1024MB	2048MB	3072MB
2048MB	0MB	2048MB
2048MB	256MB	2304MB
2048MB	512MB	2560MB

2048MB	1024MB	3072MB
2048MB	2048MB	4096MB

LAN Interface	
Item	Specification
Chipset	ATHEROS_AR8121
Supports LAN protocol	10/100/1000 Ethernet
PCI-E Giga	
LAN connector type	RJ45
LAN connector location	Left side
Features	Integrated 10/100/1000 BASE-T transceiver

Modem Interface	
Item	Specification
Data modem data baud rate (bps)	56K
Supports modem protocol	V.92
Modem connector type	RJ11
Modem connector location	Left side

Bluetooth Interface	
Item	Specification
Chipset	Built-in ICH8M
Data throughput	723 bps (full speed data rate)
Protocol	Bluetooth 1.1 (Upgradeable to Bluetooth 1.2 when SIG specification is ratified).
Interface	USB 2.0
Connector type	USB

Item	Specification
Chipset	Built-in ICH8M
Data throughput	540 Mbps

Chapter 1 33

Protocol	802.11AGN
Interface	PCI

Hard Disk Drive Interface	
Item	Specification
Vendor & Model Name	HGST HTS541680J9SA00
WD WD800BEVS-22RST0	Seagate ST9120822AS
	Toshiba MK1237GSX
	HGST HTS541612J9SA00
WD WD1200BEVS-22RST0	TOSHIBA MK1637GSX
	SEAGATE ST9160821AS
	HGST HTS541616J9SA00
	WD WD1600BEVS-22RST0
Capacity (MB)	80000
Bytes per sector	512
Data heads	2
4 for Toshiba and HGST	4
Drive Format	
Disks	1
Spindle speed (RPM)	5400 RPM
Performance Specifications	
Buffer size	8M
Interface	SATA
Max. media transfer rate (disk-buffer, Mbytes/s)	100,150
Data transfer rate (host~buffer, Mbytes/s)	
Ultra DMA mode-5	100 MB/Sec.
Ultra DMA mode-5	100 MB/Sec.
Ultra DMA mode-5	100 MB/Sec.
DC Power Requirements	
Voltage tolerance	5V(DC) +/- 5%
Data transfer rate (host~buffer, Mbytes/s)	

Ultra DMA mode-5	100 MB/Sec.
Ultra DMA mode-5	100 MB/Sec.
Ultra DMA mode-5	100 MB/Sec.
DC Power Requirements	
Voltage tolerance	5V(DC) +/- 5%

DVD-SuperMulti Interface	
Item	Specification
Vendor & model name	TOSHIBA 8X TS-L632D
	PHILIPS 8X DS-8A1P
	HLDS 8X GSA-T20N
Performance Specification	With CD Diskette
Transfer rate (KB/sec)	Sustained:Max 3.6Mbytes/sec
	Sustained:Max 10.8Mbytes/sec
Buffer Memory	2MB
Interface	Enhanced IDE(ATAPI) compatible
Applicable disc format	
Support disc formats	Reads data in each CD-ROM, CD-ROM XA, CD-1, Video CD, CD-Extra and CD-Plus
	2. Reads data in super Audio CD (SACD) Hybrid type
	3. Reads standard CD-DA
	4. Reads and writes CD-R discs
	5. Reads and writes CD-RW andHSRW discs
	6. Reads and writes US & US+RW
	7. Reads data in each DVD-ROM and DVD-Dual
	8. Reads and writes in each DVD-R (Ver. 2.0 for general), DVD-RW and DVD+R/RW (Ver1.1)
	9.Reads and writes DVD+-R Dual
	10.Reads and writes DVD-RAM
Loading mechanism	Load: Manual
	Release: (a) Electrical Release (Release Button)
	(b) Release by ATAPI command
	(c) Emergency Release

Chapter 1 35

Power Requirement	
Input Voltage	5 V +/- 5 % (Operating)

Audio Interface	
Item	Specification
Audio Controller	Realtek ALC889X
Audio onboard or optional	Built-in
Mono or Stereo	Stereo
Resolution	24 bit stereo full duplex
Compatibility	HD audio Interface; S/PDIF output for PCM or AC-3 content
Sampling rate	1Hz resolution VSR (Variable Sampling Rate)
Internal microphone	Yes
Internal speaker / Quantity	Yes/2(3W speakers)
Supports PnP DMA channel	DMA channel 0
DMA channel 1	
Supports PnP IRQ	IRQ10, IRQ11

Video Interface	
Item	Specification
Chipset	Acer MXM compatible

Video Memory	
Item	Specification
Chipset	Acer MXM compatible

USB Port	
Item	Specification
Chipset	Built-in ICH8M
USB Compliancy Level	2
OHCI	USB 1.1 and USB 2.0 Host controller
Number of USB port	4
Location	One on the left side; three on the right side

Serial port function control	Enable/Disable by BIOS Setup
------------------------------	------------------------------

Express Card Interface	
Item	Specification
Express card controller	Built-in ICH8M
Supports card type	75mmx54mm(W)x5mm
Number of slots	One
Access location	Left Side
Interface	PCI Express

System Board Major Chips	
Item	Controller
Core logic	Intel PM965/GM965 + ICH8M
VGA	Acer MXM compatible
LAN	ATHEROS_AR8121
USB 2.0	Built in ICH8M
CardReader	Jmicro JMB385
MODEM	Foxconn T60M951
Bluetooth	Foxconn T60H928.01
Wireless 802.11 a+b+g	Built-in ICH8-M
Audio	Realtek ALC889X

Keyboard	
Item	Specification
Keyboard controller	ITE 8512E
Total number of keypads	88-/89-key
Windows logo key	Yes
Internal & external keyboard work simultaneously	Plug USB keyboard to the USB port directly: Yes

Chapter 1 37

Battery	
Item	Specification
Vendor & model name	BATTERY PACK SANYO LI-ION 8 CELL2.4, 4800MAH
	BATTRY PACK SONY LI-ION 8CELL2.4, 4800MAH
Battery Type	Li-ion
Pack capacity	4800 mAH
Number of battery cell	8
Package configuration	4 cells in series, 2 series in parallel
Normal voltage	14.8V
Charge voltage	16.8+-0.2V

LCD 16.0" inch			
Item	Specification		
Vendor & model name	Samsung LTN160AT01-A01		
Screen Diagonal (mm)	16.0 inches		
Active Area (mm)	353.45(H) x 198.72(V) mm		
Display resolution (pixels)	1366x768 WXGA		
Pixel Pitch	0.25875 (H) x 0.25875(V) mm		
Pixel Arrangement	R.G.B. Vertical Stripe		
Display Mode	Normally White		
Typical White Luminance (cd/m2)			
also called Brightness	300		
Luminance Uniformity	N/A		
Contrast Ratio	600		
Response Time (Optical Rise Time/Fall Time)msec	8		
Nominal Input Voltage VDD	+3.3V		
Typical Power Consumption (watt)	4.5W		
Weight(g)	550g		
Physical Size(mm)	365x214x6.5		
Electrical Interface	Dual channel LVDS		

Support Color	262,144
Viewing Angle (degree)	
Horizontal: Right/Left	65/65
Vertial: Upper/Lower	50/50
Temperature Range(C)	
	Operating
	Storage (shipping)
	0 to +50 / -20 to +60

LCD Inverter			
Item	Specification		
Vendor & model name	TDK		
Brightness conditions	N/A		
Input voltage (V)	9~20V		
Input current (mA)	360mA (max)		
Output voltage (V, rms)	710V (1800V for kick off)		
Output current (mA, rms)	6.5mA (max)		
Output voltage frequency (k Hz)	58 KHz (max)		

AC Adaptor			
Item	Specification		
Input rating	100V AC to 240V AC, 47Hz to 63Hz		
Maximum input AC current	1.5A		
Inrush current	50A@115VAC		
	100A@230VAC		
Efficiency	85% min. @115VAC input full load		

System Power Management		
ACPI mode	Power Management	

Chapter 1 39

Mech. Off (G3)	All devices in the system are turned off completely.		
Soft Off (G2/S5)	OS initiated shutdown. All devices in the system are turned off completely.		
Working (G0/S0)	Individual devices such as the CPU and hard disc may be power managed in this state.		
Suspend to RAM (S3)	CPU set power down		
	VGA Suspend		
	PCMCIA Suspend		
	Audio Power Down		
	Hard Disk Power Down		
	CD-ROM Power Down		
	Super I/O Low Power mode		
Save to Disk (S4)	Also called Hibernation Mode. System saves all system states and data onto the disc prior to power off the whole system.		


System Utilities

BIOS Setup Utility

The BIOS Setup Utility is a hardware configuration program built into your computer's BIOS (Basic Input/Output System).

Your computer is already properly configured and optimized, and you do not need to run this utility. However, if you encounter configuration problems, you may need to run Setup. Please also refer to Chapter 4 Troubleshooting when problem arises.

To activate the BIOS Utility, press m during POST (when "Press <F2> to enter Setup" message is prompted



on the bottom of screen).

Press m to enter setup. The default parameter of F12 Boot Menu is set to "disabled". If you want to change boot device without entering BIOS Setup Utility, please set the parameter to "enabled".

Press <F12> during POST to enter multi-boot menu. In this menu, user can change boot device without entering BIOS SETUP Utility.

Invoking BIOS Setup

The setup function can only be invoked by pressing F2 when Press <F2> to enter Setup message is prompted on the bottom of screen during POST.

The setup uses a menu driven interface to allow the user to configure their system. The features are divided into 6 parts as follows:

Information Display the system informations.

Main Allows the user to specify standard IBM PC AT system parameters.

Advanced Provides advanced settings of the system.

Security Provides security settings of the system.

Boot Allows the user to specify the boot options.

Exit Allows the user to save CMOS setting and exit Setup.

NOTE: You can change the value of a parameter if it is enclosed in square brackets. Navigation keys for a particular menu are shown on the bottom of the screen. Help for parameters are found in the Item Specific Help part of the screen. Read this carefully when making changes to parameter values.

NOTE: Please note that system information is subject to different models.

Information

Phoenix TrustedCore Setup Utility				
Information Main	Advanced S	ecurity	Boot	Exit
TOTAL STREET				
CPU Type:	Genuine Intel (R)® CPU	Xxxx		
CPU Speed:	XXXX GHz			
IDE0 Model Name:	TOSHIBA MK3018GAP-(PM)	(note)		
IDE0 Serial No:	Y2554027T	(note)		
ATAPI Model Name	Slimtype DVD-RON LSD-081-(SM)	1		
System BIOS Version:	V1.00			
VGA BIOS Version:	ATI M9+XC V0.1			
Serial Number:	000000000000000000000000000000000000000	22 Byte		
Asset Tag Number:		32 Byte		
Product Name:	TravelMate xxxx	16 Byte		
Manufacturer Name:	Acer	16 Byte		
UUID:	XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	16 Byte		
F1 Help T√ Sele	ect Item F5/F6 Chan	ge Values	F9	Setup defaults
Esc Exit ←→ Se	lect Menu Enter Selec	t ▶ Sub-Menu	F10	Save and Exit

NOTE: The system information is subject to different models.

Parameter	Description	
CPU Type	This field shows the CPU type and speed of the system.	
IDE1 Model Name	This field shows the model name of HDD installed on primary IDE master.	
IDE1 Serial Number	This field displays the serial number of HDD installed on primary IDE master.	
IDE2I Model Name	This field displays the mofel name of devices installed on secondary IDE master. The hard disk drive or optical drive model name is automatically detected by the system.	
IDE2 Serial Number	This field shows the serial number of devices installed on secondary IDE master.	
System BIOS ver	Displays system BIOS version.	
VGA BIOS Ver	This field displays the VGA firmware version of the system.	
KBC Ver	This field shows the keyboard	
Serial Number	This field displays the serial number of this unit.	
Asset Tag Number	This field displays the asset tag number of the system.	
Product Name	This field shows product name of the system.	
Manufacturer Name	This field displays the manufacturer of this system.	

Parameter	Description	
UUID Number	This will be visible only when an internal LAN device is presenting.	
	UUID=32bytes	

Main

The Main screen displays a summary of your computer hardware information, and also includes basic setup parameters. It allows the user to specify standard IBM PC AT system parameters.

Phoenix TrustedCore Setup Utility						
Information	Main Advand	ed Se	curity	Boo		Exit
*			Item sp	ecific	Help	
System Time:	[09	:00:00]				
System Date:	[01	/01/2007] <	<tab>, <shift< td=""><td>-Tab></td><td>or or</td><td></td></shift<></tab>	-Tab>	or or	
		<	<enter> selec</enter>	ts fiel	d	
Total Memory:	XXX	X MB				
Video Memory:	[8M]	Note2				
Quiet Boot:	[En	abled]				
Network Boot	[En	abled]				
F12 Boot Menu	[Dis	sabled]				
D2D Recovery	[En	abled]				
SATA Mode	170	ICI Mode]				
F1 Help	↑↓ Select Item	F5/F6 Change	Values	F9	Setup defa	aults
Esc Exit	←→ Select Menu				Save and	
	V Octobe Wichia	Ziller Coloct	Cab Moria		Cave and	LAIL

NOTE: The screen above is for your reference only. Actual values may differ.


The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.

Parameter	Description	Format/Option		
System Time	Sets the system time. The hours are displayed with 24-hour format.	Format: HH:MM:SS (hour:minute:second) System Time		
System Date	Sets the system date.	Format MM/DD/YYYY (month/day/ year) System Date		
System Memory	This field reports the memory size of the system. Memory size is fixed to 640MB			
Extended Memory	This field reports the memory size of the extended memory in the system. Extended Memory size=Total memory size-1MB			
VGA Memory	Shows the VGA memory size. VGA Memory size=64/128MB			
Quiet Boot	Determines if Customer Logo will be displayed or not; shows Summary Screen is disabled or enabled. Enabled: Customer Logo is displayed, and Summary Screen is disabled. Disabled: Customer Logo is not displayed, and	Option: Enabled or Disabled		
Network Boot	Summary Screen is enabled. Enables, disables the system boot from LAN	Option: Enabled or Disabled		
F12 Boot Menu	(remote server). Enables, disables Boot Menu during POST.	Option: Disabled or Enabled		
D2D Recovery	Enables, disables D2D Recovery function. The function allows the user to create a hidden partition on hard disc drive to store operation system and restore the system to factory defaults.	Option: Enabled or Disabled		

NOTE: The sub-items under each device will not be shown if the device control is set to disable or auto. This is because the user is not allowed to control the settings in these cases.

Advanced

The Advanced screen displays advanced settings in BIOS.




The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.

Parameter	Description	Option
Serial port	Displays the settings of the serial port	Enabled or Disabled
Parallel port	Shows the settings of the parallel port	Enabled or Disabled

Security

The Security screen contains parameters that help safeguard and protect your computer from unauthorized use.



The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.

Parameter	Description	Option
User Password is	Shows the setting of the user password.	Clear or Set
Supervisor Password is	Shows the setting of the Supervisor password	Clear or Set
Set User Password	Press Enter to set the user password. When user password is set, this password protects the BIOS Setup Utility from unauthorized access. The user can enter Setup menu only and does not have right to change the value of parameters.	
Set Supervisor Password	Press Enter to set the supervisor password. When set, this password protects the BIOS Setup Utility from unauthorized access. The user can not either enter the Setup menu nor change the value of parameters.	
HardDisk Security	Enables or disables primary hard disk security function.	
Password on Boot	Defines whether a password is required or not while the events defined in this group happened. The following sub-options are all requires the Supervisor password for changes and should be grayed out if the user password was used to enter setup.	Disabled or Enabled

NOTE: When you are prompted to enter a password, you have three tries before the system halts. Don't forget your password. If you forget your password, you may have to return your notebook computer to your dealer to reset it.

Setting a Password

Follow these steps as you set the user or the supervisor password:

1. Use the w andy keys to highlight the Set Supervisor Password parameter and press the e key. The Set Supervisor Password box appears:

Set Supervisor Pas	sword	
Enter New Password	[]
Confirm New Password	[1

2. Type a password in the "Enter New Password" field. The password length can not exceeds 8 alphanumeric characters (A-Z, a-z, 0-9, not case sensitive). Retype the password in the "Confirm New Password" field.

IMPORTANT: Be very careful when typing your password because the characters do not appear on the screen.

- 3. Press e
 - After setting the password, the computer sets the User Password parameter to "Set".
- 4. If desired, you can opt to enable the Password on boot parameter.
- **5.** When you are done, press u to save the changes and exit the BIOS Setup Utility.

Removing a Password

Follow these steps:

1. Use the w and y keys to highlight the Set Supervisor Password parameter and press the e key. The Set Password box appears:

Set Supervisor Passwo	rd	
Enter current password	[]
Enter New Password	[]
Confirm New Password	[]


- 2. Type the current password in the Enter Current Password field and press e.
- **3.** Press e twice **without** typing anything in the Enter New Password and Confirm New Password fields. The computer then sets the Supervisor Password parameter to "Clear".
- 4. When you have changed the settings, press u to save the changes and exit the BIOS Setup Utility.

Changing a Password

1. Use the w and y keys to highlight the Set Supervisor Password parameter and press the e key. The Set Password box appears:

Set Supervisor Passwo	ord	
Enter current password]]
Enter New Password	[]
Confirm New Password	[]

- 2. Type the current password in the Enter Current Password field and press e.
- 3. Type a password in the Enter New Password field. Retype the password in the Confirm New Password field.
- 4. Press e. After setting the password, the computer sets the User Password parameter to "Set".
- 5. If desired, you can enable the Password on boot parameter.
- **6.** When you are done, press u to save the changes and exit the BIOS Setup Utility. If the verification is OK, the screen will display as following.



The password setting is complete after the user presses u.

If the current password entered does not match the actual current password, the screen will show you the Setup Warning.

Setup Warning Invalid password Re-enter Password [continue]

If the new password and confirm new password strings do not match, the screen will display the following message.

Setup Warning

Password do not match

Re-enter Password

Boot

This menu allows the user to decide the order of boot devices to load the operating system. Bootable devices includes the distette drive in module bay, the onboard hard disk drive and the CD-ROM in module bay.

Phoenix TrustedCore Setup Utility				
Information Main Ad	vanced	Security Item specif	Boot ic Help	Exit
Boot prioroty order :		Use <↑> or <↓> to select a device then press <f6> to move it up the List, or <f5> to move it down the list. Press <esc> to escape the</esc></f5></f6>		
1: IDE0 : WDC WD200EB –(PM) 2: IDE1: WDC WD200EB –(PM)				
3: CD/DVD		menu		
4: PCI LAN 5. USB HDD				
6. USB FDD				
7. USB Key	3			
8. USB CD/DVD ROM				
F1 Help ↑↓ Select Item	E5/E6 Cha	inge Values	F9 S	etup defaults
Esc Exit ←→ Select Menu		ect ► Sub-Menu		Save and Exit

Exit

The Exit screen contains parameters that help safeguard and protect your computer from unauthorized use.

	Phoenix TrustedCore Setup Utility				
Information	Main Adv	ranced	Security	Boot	Exit
100000			Item spec	cific Help	
Exit Saving C	Exit Saving Changes		Exit System Setup and save your changes to CMOS		
Exit Discardi	Exit Discarding Changes		Exit utility without saving Setup data to CMOS.		aving Setup
Load Setup D	Load Setup Defaults		Load default values for all SETUP item.		
Discard chan	iges				
Save change	S				
***************************************				ladik-wi-wasi lad	
F1 Help	↑↓ Select Item	F5/F6 Chang	ge Values	F9 Set	up defaults
Esc Exit	←→ Select Menu	Enter Select	t ▶ Sub-Menu	F10 S	ave and Exit

The table below describes the parameters in this screen.

Parameter	Description	
Exit Saving Changes	Exit System Setup and save your changes to CMOS.	
Exit Discarding Changes	Exit utility without saving setup data to CMOS.	
Load Setup Default	Load default values for all SETUP item.	
Discard Changes	Load previous values from CMOS for all SETUP items.	
Save Changes	Save Setup Data to CMOS.	

BIOS Flash Utility

The BIOS flash memory update is required for the following conditions:

New versions of system programs

New features or options

Restore a BIOS when it becomes corrupted.

Use the Phlash utility to update the system BIOS flash ROM.

NOTE: If you do not have a crisis recovery diskette at hand, then you should create a **Crisis Recovery Diskette** before you use the Phlash utility.

NOTE: Do not install memory-related drivers (XMS, EMS, DPMI) when you use the Phlash.

NOTE: Please use the AC adaptor power supply when you run the Phlash utility. If the battery pack does not contain enough power to finish BIOS flash, you may not boot the system because the BIOS is not completely loaded.

Fellow the steps below to run the Phlash.

- 1. Prepare a bootable diskette.
- 2. Copy the flash utilities to the bootable diskette.
- 3. Then boot the system from the bootable diskette. The flash utility has auto-execution function.

Remove HDD password Utility

This section provide you with removing HDD password method:


Remove HDD Password:

If you key in wrong HDD password for three time, "HDD password error code" would display on the screen. See the image below.


If you need to solve HDD password locked problem, you can run unlock6.EXE



- 1. Key in "unlock6 error code 205"
- 2. Select "2"
- 3. Choose one HDD password



Reboot system and key in "R6PI11X" or "MI8N4KK" to HDD user password.



Then the HDD password will be unlocked and will auto into Windows after reboot.

Machine Disassembly and Replacement

This chapter contains step-by-step procedures on how to disassemble the notebook computer Aspire 6920 for maintenance and troubleshooting.

To disassemble the computer, you need the following tools:

Wrist grounding strap and conductive mat for preventing electrostatic discharge

Small Philips screw driver

hilips screwdriver

Plastic flat head screw driver

Tweezers

NOTE: The screws for the different components vary in size. During the disassembly process, group the screws with the corresponding components to avoid mismatch when putting back the components. When you remove the stripe cover, please be careful not to scrape the cover.

Chapter 3 61

General Information


Before You Begin

Before proceeding with the disassembly procedure, make sure that you do the following:

- **1.** Turn off the power to the system and all peripherals.
- 2. Unplug the AC adapter and all power and signal cables from the system.
- **3.** Remove the battery pack.


Disassembly Procedure Flowchart

The flowchart on the succeeding page gives you a graphic representation on the entire disassembly sequence and instructs you on the components that need to be removed during servicing. For example, if you want to remove the system board, you must first remove the keyboard, then disassemble the inside assembly frame in that order.



Chapter 3 63

LCM module disassembly flow chart



Removing the Battery Pack

- 1. Release the battery.
- 2. Slide the battery latch then remove the battery.





Chapter 3 65

Removing the HDD/Memory Module/Wireless LAN Card/TV Tuner Card/System Fan/Thermal Modules/CPU

Removing the HDD


- 1. Remove the six screws fastening the CTO cover
- 2. Detach the CTO cover from the notebook.





Removing the Wireless Cover & RAM Module

- 3. Remove one screw to release the Wireless cover
- 4. Remove the Wireless cover from the notebook.
- **5.** Pop out the memory module from the DIMM socket then remove it (If the notebook has two memory modules, then repeat this step).



Removing the Wireless LAN Card/TV Tunder Card and System Fan

- 6. Pull out the Wireless antenna.
- 7. Remove the two screws fastening the wireless LAN card.

- 8. Disconnect the main and auxiliary antennae from the wireless LAN card.
- 9. Then take out the wireless LAN card from the main unit.
- 10. Loose two screws from the TV card.
- 11. Remove the TV card from the machine.



- 12. Remove the two screws from the Wireless card.
- 13. Remove the Wireless card from the machine.



- **14.** Remove HDD module as shown.
- **15.** Unplug power cable from the machine.




- 16. Remove FAN cable from the machine.
- 17. Loose the FAN screw.
- **18.** Take out the system fan from the main unit as shown.

Chapter 3 67



Removing the Thermal Modules and the CPU

- 19. Remove the two screws holding the finger heatsink.
- **20.** Detach the finger heatsink from the main board.
- 21. Then take out the CPU heatsink from the main board.
- 22. Use a flat screwdriver to release the CPU lock (Turn counter clock-wise) then remove the CPU carefully.




- 23. Remove the Express dummy card.
- 24. Remove the card reader dummy.



Removing the ODD and Dummy cards

- **25.** Remove the screw fastening the optical disk drive module on the bottom.
- 26. Use a tool to push the optical disk drive module outwards and remove the ODD module



Removing the Hinge cover


- 27. Remove two hinge cover screws.
- 28. Then detach the Hinge cover from both side.



Chapter 3 69

Removing the BTCB screws

29. Loose 21 screws from BTCB.



30. Detach Switch cover.



31. Disconnect Media board FFC from the Switch cover

Disassembling the Main Unit

- 1. Turn over the keyboard as the image shows.
- 2. Disconnect the Keyboard FFC from the main board
- 3. Then remove the keyboard from the main unit.



- **4.** Remove the 18 screws fastening the upper case and the lower case assembly as shown.
- 5. Disconnect the FFC from the main board.



- 6. Loose two screws from the TPCB.
- 7. Disconnect the LCM cable.
- 8. Pull out the Power cable.
- 9. Pull out the Wireless antenna.
- 10. Release four TPCB locker then remove the TCB from machine.








Chapter 3 71



Disassembling the LED boards

- 11. Loose the LED boards four screws.
- 12. Remove two LED boards from the machine.




- 13. Loose four LCM hinge screws.
- **14.** Then remove LCM module from the machine.





Remove I/O baord and Main Board.

- **15.** Loose the daughter board screw then remove the daughter board from the machine.
- **16.** Disconnect four cables on the M/B as shown.
- 17. Loose the M/B screw, remove RJ11 connector from the BTCB.
- 18. Remove M/B from the BTCB.



Chapter 3 73

- 19. Disconnect LED/B cable and USB/B FFC.
- 20. Remove the USB board from BTCB..




- 21. Loose two Modem card screws.
- 22. Disconnect Modem card cable.
- 23. Remove Modem card from the M/B.

Disassembly LCM module

- 1. Remove six LCM bezel mylar.
- 2. Loose 11 LCM bezel screws.
- 3. Remove LCM bezel.



- 4. Disconnect Inverter cable and Back LED board cable.
- 5. Disconnect CCD cable...




- 6. Loose four LCD scrws from the hinge.
- 7. Remove the LCD panel.



8. Remove the Inverter board.



9. Loose four LCD hinge screws, then remove two hinges from LCD panel.



Chapter 3 75

Disassembling the External Modules

Disassembling the HDD Module

- 1. Remove the four screws holding the HDD (hard disk drive) foil; two on each side.
- 2. Carefully take out the hard disk drive from the HDD foil.



Disassembling the ODD Module

- 1. Remove the two screws holding the optical bracket.
- 2. Then remove the optical bracket from the optical disk drive.



Troubleshooting

Use the following procedure as a guide for computer problems.

NOTE: The diagnostic tests are intended to test only Acer products. Non-Acer products, prototype cards, or modified options can give false errors and invalid system responses.

- 1. Obtain the failing symptoms in as much detail as possible.
- 2. Verify the symptoms by attempting to re-create the failure by running the diagnostic test or by repeating the same operation.
- 3. Use the following table with the verified symptom to determine which page to go to.

Symptoms (Verified)	Go To
Power failure. (The power indicator does not go on or stay on.)	"Power System Check" on page 81.
POST does not complete. No beep or error codes are indicated.	"Power-On Self-Test (POST) Error Message" on page 84
	"Undetermined Problems" on page 96
POST detects an error and displayed messages on screen.	"Error Message List" on page 85
Other symptoms (i.e. LCD display problems or others).	"Power-On Self-Test (POST) Error Message" on page 84
Symptoms cannot be re-created (intermittent problems).	Use the customer-reported symptoms and go to "Power-On Self-Test (POST) Error Message" on page 84
	"Intermittent Problems" on page 95
	"Undetermined Problems" on page 96

System Check Procedures

External Diskette Drive Check

Do the following to isolate the problem to a controller, driver, or diskette. A write-enabled, diagnostic diskette is required.

NOTE: Make sure that the diskette does not have more than one label attached to it. Multiple labels can cause damage to the drive or cause the drive to fail.

Do the following to select the test device.

- 1. Boot from the diagnostics diskette and start the diagnostics program.
- 2. See if FDD Test is passed as the program runs to FDD Test.
- 3. Follow the instructions in the message window.

If an error occurs with the internal diskette drive, reconnect the diskette connector on the system board.

If the error still remains:

- Reconnect the external diskette drive/DVD-ROM module.
- 2. Replace the external diskette drive/CD-ROM module.
- Replace the main board.

External CD-ROM Drive Check

Do the following to isolate the problem to a controller, drive, or CD-ROM. Make sure that the CD-ROM does not have any label attached to it. The label can cause damage to the drive or can cause the drive to fail.

Do the following to select the test device:

- Boot from the diagnostics diskette and start the diagnostics program.
- See if CD-ROM Test is passed when the program runs to CD-ROM Test.
- 3. Follow the instructions in the message window.

If an error occurs, reconnect the connector on the System board. If the error still remains:

- 1. Reconnect the external diskette drive/CD-ROM module.
- 2. Replace the external diskette drive/CD-ROM module.
- 3. Replace the main board.

Keyboard or Auxiliary Input Device Check

Remove the external keyboard if the internal keyboard is to be tested.

If the internal keyboard does not work or an unexpected character appears, make sure that the flexible cable extending from the keyboard is correctly seated in the connector on the system board.

If the keyboard cable connection is correct, run the Keyboard Test.

If the tests detect a keyboard problem, do the following one at a time to correct the problem. Do not replace a non-defective FRU:

- Reconnect the keyboard cables.
- 2. Replace the keyboard.
- Replace the main board.

The following auxiliary input devices are supported by this computer:

Numeric keypad

External keyboard

If any of these devices do not work, reconnect the cable connector and repeat the failing operation.

Memory check

Memory errors might stop system operations, show error messages on the screen, or hang the system.

- 1. Boot from the diagnostics diskette and start the doagmpstotics program (please refer to main board.
- 2. Go to the diagnostic memory in the test items.
- 3. Press F2 in the test items.
- 4. Follow the instructions in the message window.

NOTE: Make sure that the DIMM is fully installed into the connector. A loose connection can cause an error.

Power System Check

To verify the symptom of the problem, power on the computer using each of the following power sources:

- 1. Remove the battery pack.
- 2. Connect the power adapter and check that power is supplied.
- 3. Disconnect the power adapter and install the charged battery pack; then check that power is supplied by the battery pack.


If you suspect a power problem, see the appropriate power supply check in the following list:

"Check the Power Adapter" on page 82

"Check the Battery Pack" on page 83

Check the Power Adapter

Unplug the power adapter cable from the computer and measure the output voltage at the plug of the power adapter cable. See the following figure



- 1. If the voltage is not correct, replace the power adapter.
- **2.** If the voltage is within the range, do the following:

Replace the System board.

If the problem is not corrected, see "Undetermined Problems" on page 96.

If the voltage is not correct, go to the next step.

NOTE: An audible noise from the power adapter does not always indicate a defect.

- **3.** If the power-on indicator does not light up, check the power cord of the power adapter for correct continuity and installation.
- 4. If the operational charge does not work, see "Check the Battery Pack" on page 83.

Check the Battery Pack


To check the battery pack, do the following:

From Software:

- 1. Check out the Power Management in control Panel
- In Power Meter, confirm that if the parameters shown in the screen for Current Power Source and Total Battery Power Remaining are correct.
- 3. Repeat the steps 1 and 2, for both battery and adapter.
- 4. This helps you identify first the problem is on recharging or discharging.

From Hardware:

- 1. Power off the computer.
- 2. Remove the battery pack and measure the voltage between battery terminals 1(+) and 6(ground). See the following figure



3. If the voltage is still less than 7.5 Vdc after recharging, replace the battery.

To check the battery charge operation, use a discharged battery pack or a battery pack that has less than 50% of the total power remaining when installed in the computer.

If the battery status indicator does not light up, remove the battery pack and let it return to room temperature. Re-install the battery pack.

If the charge indicator still does not light up, replace the battery pack. If the charge indicator still does not light up, replace the DC/DC charger board.

Touchpad Check

If the touchpad doesn't work, do the following actions one at a time to correct the problem. Do not replace a non-defective FRU:

- Reconnect the touchpad cables.
- 2. Replace the touchpad.
- 3. Replace the system board.

After you use the touchpad, the pointer drifts on the screen for a short time. This self-acting pointer movement can occur when a slight, steady pressure is applied to the touchpad pointer. This symptom is not a hardware problem. No service actions are necessary if the pointer movement stops in a short period of time.

Power-On Self-Test (POST) Error Message

The POST error message index lists the error message and their possible causes. The most likely cause is listed first.

NOTE: Perform the FRU replacement or actions in the sequence shown in FRU/Action column, if the FRU replacement does not solve the problem, put the original part back in the computer. Do not replace a non-defective FRU.

This index can also help you determine the next possible FRU to be replaced when servicing a computer.

If the symptom is not listed, see "Undetermined Problems" on page 96.

The following lists the error messages that the BIOS displays on the screen and the error symptoms classified by function.

NOTE: Most of the error messages occur during POST. Some of them display information about a hardware device, e.g., the amount of memory installed. Others may indicate a problem with a device, such as the way it has been configured.

NOTE: If the system fails after you make changes in the BIOS Setup Utility menus, reset the computer, enter Setup and install Setup defaults or correct the error.

Index of Error Messages

Error Code List

Error Codes	Error Messages
006	Equipment Configuration Error
	Causes:
	CPU BIOS Update Code Mismatch
	2. IDE Primary Channel Master Drive Error
	(THe causes will be shown before "Equipment Configuration Error")
010	Memory Error at xxxx:xxxx:xxxxh (R:xxxxh, W:xxxxh)
070	Real Time Clock Error
071	CMOS Battery Bad
072	CMOS Checksum Error
110	System disabled.
	Incorrect password is specified.
<no code="" error=""></no>	Battery critical LOW
	In this situation BIOS will issue 4 short beeps then shut down system, no message will show.
<no code="" error=""></no>	Thermal critical High
No end code	3
	In this situation BIOS will shut down system, not show message.

Error Message List

Error Messages	FRU/Action in Sequence
Failure Fixed Disk	Reconnect hard disk drive connector.
	"Load Default Settings" in BIOS Setup Utility.
	Hard disk drive
	System board
Stuck Key	see "Keyboard or Auxiliary Input Device Check" on page 80.
Keyboard error	see "Keyboard or Auxiliary Input Device Check" on page 80.
Keyboard Controller Failed	see "Keyboard or Auxiliary Input Device Check" on page 80.
Keyboard locked - Unlock key switch	Unlock external keyboard
Monitor type does not match CMOS - Run Setup	Run "Load Default Settings" in BIOS Setup Utility.
Shadow RAM Failed at offset: nnnn	BIOS ROM
	System board
System RAM Failed at offset: nnnn	DIMM
	System board
Extended RAM Failed at offset: nnnn	DIMM
	System board
System battery is dead - Replace and run Setup	Replace RTC battery and Run BIOS Setup Utility to reconfigure system time, then reboot system.
System CMOS checksum bad - Default	RTC battery
configuration used	Run BIOS Setup Utility to reconfigure system time, then reboot system.
System timer error	RTC battery
	Run BIOS Setup Utility to reconfigure system time, then reboot
	system.
	System board

Error Message List

Error Messages	FRU/Action in Sequence
Real time clock error	RTC battery
	Run BIOS Setup Utility to reconfigure system time, then reboot
	system.
	System board
Previous boot incomplete - Default configuration	Run "Load Default Settings" in BIOS Setup Utility.
used	RTC battery
	System board
Memory size found by POST differed from	Run "Load Default Settings" in BIOS Setup Utility.
CMOS	DIMM
	System board
Diskette drive A error	Check the drive is defined with the proper diskette type in BIOS
	Setup Utility See "External Diskette Drive Check" on page 80.
Incorrect Drive A type - resp CETUD	
Incorrect Drive A type - run SETUP	Check the drive is defined with the proper diskette type in BIOS Setup Utility
System cache error - Cache disabled	System board
CPU ID:	System board
DMA Test Failed	DIMM
	System board
Software NMI Failed	DIMM
	System board
Fail-Safe Timer NMI Failed	DIMM
	System board
Device Address Conflict	Run "Load Default Settings" in BIOS Setup Utility.
	RTC battery
	System board
Allocation Error for device	Run "Load Default Settings" in BIOS Setup Utility.
	RTC battery
	System board
Failing Bits: nnnn	DIMM
	BIOS ROM
	System board
Fixed Disk n	None
Invalid System Configuration Data	BIOS ROM
	System board
I/O device IRQ conflict	Run "Load Default Settings" in BIOS Setup Utility.
	RTC battery
	System board
Operating system not found	Enter Setup and see if fixed disk and drive A: are properly identified.
	Diskette drive
	Hard disk drive
	System board

Error Message List

No beep Error Messages	FRU/Action in Sequence
No beep, power-on indicator turns off and LCD is blank.	Power source (battery pack and power adapter). See "Power System Check" on page 81
	Ensure every connector is connected tightly and correctly.
	Reconnect the DIMM.
	LED board.
	System board.
No beep, power-on indicator turns on and LCD is blank.	Power source (battery pack and power adapter). See "Power System Check" on page 81
	Reconnect the LCD connector
	Hard disk drive
	LCD inverter ID
	LCD cable
	LCD Inverter
	LCD
	System board
No beep, power-on indicator turns on and LCD is	Reconnect the LCD connectors.
blank. But you can see POST on an external	LCD inverter ID
CRT.	LCD cable
	LCD inverter
	LCD
	System board
No beep, power-on indicator turns on and a	Ensure every connector is connected tightly and correctly.
blinking cursor shown on LCD during POST.	System board
No beep during POST but system runs correctly.	Speaker
	System board

Phoenix BIOS Beep Codes

Code	Beeps	POST Routine Description
02h		Verify Real Mode
03h		Disable Non-Maskable Interrupt (NMI)
04h		Get CPU type
06h		Initialize system hardware
08h		Initialize chipset with initial POST values
09h		Set IN POST flag
0Ah		Initialize CPU registers
0Bh		Enable CPU cache
0Ch		Initialize caches to initial POST values
0Eh		Initialize I/O component
0Fh		Initialize the local bus IDE
10h		Initialize Power Management
11h		Load alternate registers with initial POST values
12h		Restore CPU control word during warm boot
13h		Initialize PCI Bus Mastering devices
14h		Initialize keyboard controller
16h	1-2-2-3	BIOS ROM checksum
17h		Initialize cache before memory autosize
18h		8254 timer initialization
1Ah		8237 DMA controller initialization
1Ch		Reset Programmable Interrupt Controller
20h	1-3-1-1	Test DRAM refresh
22h	1-3-1-3	Test 8742 Keyboard Controller
24h		Set ES segment register to 4 GB
26h		Enable A20 line
28h		Autosize DRAM
29h		Initialize POST Memory Manager
2Ah		Clear 215 KB base RAM
2Ch	1-3-4-1	RAM failure on address line xxxx
2Eh	1-3-4-3	RAM failure on data bits xxxx of low byte of memory bus
2Fh		Enable cache before system BIOS shadow
30h	1-4-1-1	RAM failure on data bits xxxx of high byte of memory bus
32h		Test CPU bus-clock frequency
33h		Initialize Phoenix Dispatch Manager
36h		Warm start shut down
38h		Shadow system BIOS ROM
3Ah		Autosize cache
3Ch		Advanced configuration of chipset registers
3Dh		Load alternate registers with CMOS values
42h		Initialize interrupt vectors
45h		POST device initialization

Code	Beeps	POST Routine Description
46h	2-1-2-3	Check ROM copyright notice
48h		Check video configuration against CMOS
49h		Initialize PCI bus and devices
4Ah		Initialize all video adapters in system
4Bh		QuietBoot start (optional)
4Ch		Shadow video BIOS ROM
4Eh		Display BIOS copyright notice
50h		Display CPU type and speed
51h		Initialize EISA board
52h		Test keyboard
54h		Set key click if enabled
58h	2-2-3-1	Test for unexpected interrupts
59h		Initialize POST display service
5Ah		Display prompt "Press F2 to enter SETUP"
5Bh		Disable CPU cache
5Ch		Test RAM between 512 and 640 KB
60h		Test extended memory
62h		Test extended memory address lines
64h		Jump to User Patch1
66h		Configure advanced cache registers
67h		Initialize Multi Processor APIC
68h		Enable external and CPU caches
69h		Setup System Management Mode (SMM) area
6Ah		Display external L2 cache size
6Bh		Load custom defaults (optional)
6Ch		Display shadow-area message
6Eh		Display possible high address for UMB recovery
70h		Display error messages
72h		Check for configuration errors
76h		Check for keyboard errors
7Ch		Set up hardware interrupt vectors
7Eh		Initialize coprocessor if present
80h		Disable onboard Super I/O ports and IRQs
81h		Late POST device initialization
82h		Detect and install external RS232 ports
83h		Configure non-MCD IDE controllers
84h		Detect and install external parallel ports
85h		Initialize PC-compatible PnP ISA devices
86h		Re-initialize onboard I/O ports
87h		Configure Motherboard Configurable Devices (optional)
88h		Initialize BIOS Area
89h		Enable Non-Maskable Interrupts (NMIs)
8Ah		Initialize Extended BIOS Data Area
8Bh		Test and initialize PS/2 mouse

8Ch Initialize floppy controller 8Fh Determine number of ATA drives (optional) 90h Initialize hard-disk controllers 91h Initialize local-bus hard-disk controllers 92h Jump to UserPatch2 93h Build MPTABLE for multi-processor boards 95h Install CD ROM for boot 96h Clear huge ES segment register 97h Fixup Multi Processor table 98h 1-2 Search for option ROMs. One long, two shot beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock A4h Initialize Typematic rate
90h Initialize hard-disk controllers 91h Initialize local-bus hard-disk controllers 92h Jump to UserPatch2 93h Build MPTABLE for multi-processor boards 95h Install CD ROM for boot 96h Clear huge ES segment register 97h Fixup Multi Processor table 98h 1-2 Search for option ROMs. One long, two sho beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day Check key lock
91h Initialize local-bus hard-disk controllers 92h Jump to UserPatch2 93h Build MPTABLE for multi-processor boards 95h Install CD ROM for boot 96h Clear huge ES segment register 97h Fixup Multi Processor table 98h 1-2 Search for option ROMs. One long, two shot beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
92h Jump to UserPatch2 93h Build MPTABLE for multi-processor boards 95h Install CD ROM for boot 96h Clear huge ES segment register 97h Fixup Multi Processor table 98h 1-2 Search for option ROMs. One long, two sho beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
93h Build MPTABLE for multi-processor boards 95h Install CD ROM for boot 96h Clear huge ES segment register 97h Fixup Multi Processor table 98h 1-2 Search for option ROMs. One long, two shot beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
95h Install CD ROM for boot 96h Clear huge ES segment register 97h Fixup Multi Processor table 98h 1-2 Search for option ROMs. One long, two sho beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
96h Clear huge ES segment register 97h Fixup Multi Processor table 98h 1-2 Search for option ROMs. One long, two shot beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
97h Fixup Multi Processor table 98h 1-2 Search for option ROMs. One long, two sho beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day Check key lock
98h 1-2 Search for option ROMs. One long, two sho beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
beeps on checksum failure. 99h Check for SMART drive (optional) 9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day Check key lock
9Ah Shadow option ROMs 9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
9Ch Set up Power Management 9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
9Dh Initialize security engine (optional) 9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
9Eh Enable hardware interrupts 9Fh Determine number of ATA and SCSI drives A0h Set time of day A2h Check key lock
9Fh Determine number of ATA and SCSI drives A0h Set time of day Check key lock
A0h Set time of day A2h Check key lock
A2h Check key lock
A4h Initialize Typematic rate
A8h Erase F2 prompt
AAh Scan for F2 key stroke
ACh Enter SETUP
AEh Clear Boot flag
B0h Check for errors
B2h POST done- prepare to boot operating syste
B4h 1 One short beep before boot
B5h Terminate QuietBoot (optional)
B6h Check password (optional)
B9h Prepare Boot
BAh Initialize DMI parameters
BBh Initialize PnP Option ROMs
BCh Clear parity checkers
BDh Display MultiBoot menu
BEh Clear screen (optional)
BFh Check virus and backup reminders
C0h Try to boot with INT 19
C1h Initialize POST Error Manager (PEM)
C2h Initialize error logging
C3h Initialize error display function
C4h Initialize system error handler
C5h PnPnd dual CMOS (optional)
C6h Initialize notebook docking (optional)
C7h Initialize notebook docking late
C8h Force check (optional)
C9h Extended checksum (optional)

Code	Beeps	POST Routine Description
D2h		Unknown interrupt

Code	Beeps	
E0h		Initialize the chipset
E1h		Initialize the bridge
E2h		Initialize the CPU
E3h		Initialize the system timer
E4h		Initialize system I/O
E5h		Check force recovery boot
E6h		Checksum BIOS ROM
E7h		Go to BIOS
E8h		Set Huge Segment
E9h		Initialize Multi Processor
EAh		Initialize OEM special code
EBh		Initialize PIC and DMA
ECh		Initialize Memory type
EDh		Initialize Memory size
EEh		Shadow Boot Block
EFh		System memory test
F0h		Initialize interrupt vectors
F1h		Initialize Run Time Clock
F2h		Initialize video
F3h		Initialize System Management Mode
F4h	1	Output one beep before boot
F5h		Boot to Mini DOS
F6h		Clear Huge Segment
F7h		Boot to Full DOS

Index of Symptom-to-FRU Error Message

LCD-Related Symptoms

Symptom / Error	Action in Sequence
LCD backlight doesn't work	Enter BIOS Utility to execute "Load Setup Default Settings", then
LCD is too dark	reboot system.
LCD brightness cannot be adjusted	Reconnect the LCD connectors.
LCD contrast cannot be adjusted	Keyboard (if contrast and brightness function key doesn't work).
	LCD inverter ID
	LCD cable
	LCD inverter
	LCD
	System board
Unreadable LCD screen	Reconnect the LCD connector
Missing pels in characters	LCD inverter ID
Abnormal screen	LCD cable
Wrong color displayed	LCD inverter
	LCD
	System board
LCD has extra horizontal or vertical lines	LCD inverter ID
displayed.	LCD inverter
	LCD cable
	LCD
	System board

Indicator-Related Symptoms

Symptom / Error	Action in Sequence
Indicator incorrectly remains off or on, but system	Reconnect the inverter board
runs correctly	Inverter board
	System board

Power-Related Symptoms

Symptom / Error	Action in Sequence
Power shuts down during operation	Power source (battery pack and power adapter). See "Power System Check" on page 81.
	Battery pack
	Power adapter
	Hard drive & battery connection board
	System board
The system doesn't power-on.	Power source (battery pack and power adapter). See "Power System Check" on page 81.
	Battery pack
	Power adapter
	Hard drive & battery connection board
	System board
The system doesn't power-off.	Power source (battery pack and power adapter). See "Power System Check" on page 81.
	Hold and press the power switch for more than 4 seconds.
	System board

Power-Related Symptoms

Symptom / Error	Action in Sequence
Battery can't be charged	See "Check the Battery Pack" on page 83.
	Battery pack
	System board

PCMCIA-Related Symptoms

Symptom / Error	Action in Sequence
System cannot detect the PC Card (PCMCIA)	PCMCIA slot assembly
	System board
PCMCIA slot pin is damaged.	PCMCIA slot assembly

Memory-Related Symptoms

Symptom / Error	Action in Sequence
Memory count (size) appears different from actual size.	Enter BIOS Setup Utility to execute "Load Default Settings, then reboot system.
	DIMM
	System board

Speaker-Related Symptoms

Symptom / Error	Action in Sequence
In Windows, multimedia programs, no sound	Audio driver
comes from the computer.	Speaker
	System board
Internal speakers make noise or emit no sound.	Speaker
	System board

Power Management-Related Symptoms

Symptom / Error	Action in Sequence
The system will not enter hibernation	See "Save to Disk (S4)" on page 45.
	Keyboard (if control is from the keyboard)
	Hard disk drive
	System board
The system doesn't enter hibernation mode and	Press Fn+0and see if the computer enters hibernation mode.
four short beeps every minute.	Touchpad
	Keyboard
	Hard disk connection board
	Hard disk drive
	System board
The system doesn't enter standby mode after	See "Save to Disk (S4)" on page 45.
closing the LCD	LCD cover switch
	System board
The system doesn't resume from hibernation	See "Save to Disk (S4)" on page 45.
mode.	Hard disk connection board
	Hard disk drive
	System board
The system doesn't resume from standby mode after opening the LCD.	See "Save to Disk (S4)" on page 45.
	LCD cover switch
	System board

Power Management-Related Symptoms

Symptom / Error	Action in Sequence
Battery fuel gauge in Windows doesn't go higher than 90%.	Remove battery pack and let it cool for 2 hours. Refresh battery (continue use battery until power off, then charge battery). Battery pack System board
System hangs intermittently.	Reconnect hard disk/CD-ROM drives. Hard disk connection board System board

Peripheral-Related Symptoms

Symptom / Error	Action in Sequence
System configuration does not match the installed devices.	Enter BIOS Setup Utility to execute "Load Default Settings", then reboot system.
	Reconnect hard disk/CD-ROM/diskette drives.
External display does not work correctly.	Press Fn+F5, LCD/CRT/Both display switching
	System board
USB does not work correctly	System board
Print problems.	Ensure the "Parallel Port" in the "Onboard Devices Configuration" of BIOS Setup Utility is set to Enabled.
	Onboard Devices Configuration
	Run printer self-test.
	Printer driver
	Printer cable
	Printer
	System Board
Serial or parallel port device problems.	Ensure the "Serial Port" in the Devices Configuration" of BIOS Setup Utility is set to Enabled.
	Device driver
	Device cable
	Device
	System board

Keyboard/Touchpad-Related Symptoms

Symptom / Error	Action in Sequence
Keyboard (one or more keys) does not work.	Reconnect the keyboard cable.
	Keyboard
	System board
Touchpad does not work.	Reconnect touchpad cable.
	Touchpad board
	System board

Modem-Related Symptoms

Symptom / Error	Action in Sequence
Internal modem does not work correctly.	Modem phone port
	modem combo board
	System board

NOTE: If you cannot find a symptom or an error in this list and the problem remains, see "Undetermined Problems" on page 96.

Intermittent Problems

Intermittent system hang problems can be caused by a variety of reasons that have nothing to do with a hardware defect, such as: cosmic radiation, electrostatic discharge, or software errors. FRU replacement should be considered only when a recurring problem exists.

When analyzing an intermittent problem, do the following:

- 1. Run the advanced diagnostic test for the system board in loop mode at least 10 times.
- 2. If no error is detected, do not replace any FRU.
- 3. If any error is detected, replace the FRU. Rerun the test to verify that there are no more errors.

Undetermined Problems

The diagnostic problems does not identify which adapter or device failed, which installed devices are incorrect, whether a short circuit is suspected, or whether the system is inoperative.

Follow these procedures to isolate the failing FRU (do not isolate non-defective FRU).

NOTE: Verify that all attached devices are supported by the computer.

NOTE: Verify that the power supply being used at the time of the failure is operating correctly. (See "Power System Check" on page 81.):

- 1. Power-off the computer.
- 2. Visually check them for damage. If any problems are found, replace the FRU.
- 3. Remove or disconnect all of the following devices:

Non-Acer devices

Printer, mouse, and other external devices

Battery pack

Hard disk drive

DIMM

CD-ROM/Diskette drive Module


PC Cards

- 4. Power-on the computer.
- **5.** Determine if the problem has changed.
- **6.** If the problem does not recur, reconnect the removed devices one at a time until you find the failing FRU.
- 7. If the problem remains, replace the following FRU one at a time. Do not replace a non-defective FRU:

System board


LCD assembly

Jumper and Connector Locations



Aspi	Aspire6920 M/B layout and connector location TOP view		
No.	Name	Description	
1	CN1	LED/B Cable CNTR	
2	CN2	LCM Cable CNTR	
3	CN3	Key board FFC CNTR	
4	CN4	USB board CNTR	
5	CN7	Hot Key Board CNTR	
6	U8	South Bridge	
7	CN12	Touch pad FFC CNTR	
8	CN14	I/O Board CNTR	
9	CN15	BT cable CNTR	
10	CN13	Express card CNTR	
11	CN10	Speaker cable CNTR	
12	CN9	Media consle Board CNTR	
13	CN8	Power Board FFC CNTR	

Chapter 5 97



Bottom View

Bottom view		
No.	Name	Description
1	CN6002	W/LAN card board CNTR
2	CN6001	TV/Robson card CNTR
3	CN1003	USB Port
4	CN1002	USB Port
5	CN1005	USB Board CNTR
6	CN501	VGA Port
7	Jack501	RJ45
8	CN505	USB Port
9	CN508	HDMI Port
10	Jack502	SPDIF
11	Jack503	MIC jack
12	Jack504	Line in jack
13	CN516	MDC Card CNTR
14	CN512	New card socket
15	CN511/513	DIMM socket
16	CN514	HDD CNTR
17	CN515	PCI-E socket
18	CN510	ODD CNTR
19	U517	North Bridge
20	CN507	CPU Socket
21	CN506	VGA Card Socket

Chapter 5 99

FRU (Field Replaceable Unit) List


This chapter gives you the FRU (Field Replaceable Unit) listing in global configurations of Aspire 6920. Refer to this chapter whenever ordering for parts to repair or for RMA (Return Merchandise Authorization).


Please note that WHEN ORDERING FRU PARTS, you should check the most up-to-date information available on your regional web or channel. For whatever reasons a part number change is made, it will not be noted on the printed Service Guide. For ACER AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code from those given in the FRU list of this printed Service Guide. You MUST use the local FRU list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

NOTE: To scrap or to return the defective parts, you should follow the local government ordinance or regulations on how to dispose it properly, or follow the rules set by your regional Acer office on how to return it.


Chapter 6 99


Aspire6920 Exploded Diagram





Chapter 6 101





Chapter 6 103

CATEGORY	PARTNAME	ACER PART NO.
ACCESSORY		
THE TRIBET IN THE PARTY OF THE	REMOTE CONTROLLER FOMOSA21 RC804V-B EU	RT.22700.008
	REMOTE CONTROLLER FOMOSA21 RC804V-B TC	RT.22700.009
	REMOTE CONTROLLER FOMOSA21 RC804V-B SC	RT.22700.010
	REMOTE CONTROLLER FOMOSA21 RC804V-B EN	RT.22700.011
	WISTRON ACER XPRESS CARD PHONE KIT REV 2.0	LC.VIP00.014
	EXTERNAL ANTENNA SET	25.AAMVN.004
ADAPTER		
	ADAPTER 65W 3PINS DELTA SADP-65KB DFA YELLOW 1.7X5.5X11 LF LEVEL4	AP.06501.013
	ADAPTER 65W 3PINS LITEON PA-1650-02AC 1.7X5.5X11 LF LEVEL4	AP.06503.016
	ADAPTER 65W 3PINS HIPRO HP-OK065B13 1.7X5.5X11 LF LEVEL4	AP.0650A.010
	ADAPTER 90W 3PINS DELTA ADP-90SB BBEA 1.7X5.5X11 LF LEVEL4	AP.09001.013
	ADAPTER 90W LITE-ON PA- 1900-24AR BLUE 1.7X5.5X11 LF LEVEL4	AP.09003.011
	ADAPTER 90W HIPRO HP- OL093B13P BLUE 1.7X5.5X11 LF LEVEL4	AP.0900A.001
BATTERY		

CONTROL OF THE PARTY OF THE PAR	BATTERY LI-ION 6CELL SANYO AS-2007B 3S2P 4400MAH	BT.00603.042
	BATTERY LI-ION 6CELL SONY AS-2007B 3S2P 4400MAH	BT.00604.025
	BATTERY LI-ION 6CELL PANASONIC AS-2007B 3S2P 4400MAH	BT.00605.021
	BATTERY LI-ION 6CELL SIMPLO AS-2007B 3S2P 4400MAH	BT.00607.016
	BATTERY LI-ION 8CELL SANYO AS-2007B 4S2P 4800MAH	BT.00803.024
	BATTERY LI-ION 8CELL SONY AS-2007B 4S2P 4800MAH	BT.00804.020
	BATTERY LI-ION 8CELL PANASONIC AS-2007B 4S2P 4800MAH	BT.00805.011
	BATTERY LI-ION 8CELL SIMPLO AS-2007B 4S2P 4800MAH	BT.00807.015
BOARD		
SCH-2045NRD-795	BLUETOOTH BOARD FOXCONN BCM2045 V2 T60H928.11	BT.21100.005
	MAINBOARD AS6920G INTEL PM965 ICH8M ATHEROS AR8121 LF	MB.APQ0B.001

Chapter 6 105

MAINBOARD AS6920 INTEL GM965 ICH8M ATHEROS AR8121 LF	MB.APD0B.001
LED BOARD RIGHT	55.APQ0N.009
LED BOARD LEFT	55.APQ0N.010
TOUCHPAD BUTTON BOARD	55.APQ0N.004
HOTKEY BOARD	55.APQ0N.002
MEDIA BOARD MODULE	55.APQ0N.005

T T	1
POWER BUTTON BOARD	55.APQ0N.003
E-KEY BOARD	55.APQ0N.006
USB BOARD W/O TV CABLE	55.APQ0N.008
USB BOARD WITH TV CABLE	55.AP40N.001
I/O BOARD	55.APQ0N.007
VOA 04 PR 1 // 1/2 - 2 - 2	FF ///FOU 05 :
VGA CARD nVidia NB8P-GS DDRII 512MB 400MHz 32*16 MXM II W/ HDCP (IEC VBIOS)	55.AKE0N.004

The Province of the Province o	WIRELESS LAN BOARD 802.11AGN INTEL 4965AGN MOW1 MINI PCI	KI.KDN01.001
	WIRELESS LAN BOARD 802.11AGN INTEL 4965AGN MOW2 MINI PCI	KI.KDN01.002
	WIRELESS LAN BOARD 802.11AGN INTEL 4965AGN ROW MINI PCI	KI.KDN01.003
	MINI WIRELESS BOARD 802.11ABG MOW1 INTEL MM872612	KI.GLN01.001
	MINI WIRELESS BOARD 802.11 ABG MOW2 INTEL MM872659	KI.GLN01.002
	MINI WIRELESS BOARD 802.11 ABG ROW INTEL MM874511	KI.GLN01.003
	MINI WIRELESS LAN BOARD 802.11BG INTEL 3945BG	KI.GLN01.005
TUCHTOOT-475-00004291B	TV TUNER MINI CARD AVERMEDIA DVB-T A309 REV 1.0	TU.23100.014
	TV TUNER MINI CARD LITEON DVB-T TT-1260DA REV D	TU.23100.015
X1680x002792010962300	ROBSON BOARD 1GB INTEL NVCPEMWR001G1 LF	KI.1GB0N.002
	FINGER PRINT BOARD	55.APQ0N.001

The state of the s	TOUCHPAD SYNAPTICS TM- 00372-012	56.APQ0N.001
FX2250000975200562330 TEMA 455.00	MODEM BOARD FOXCONN MC4Z MDC1.5_3 3.3V T60M955.00	FX.22500.009
	MODEM BOARD MDC 1.5 FOXCONN T60M951.41 (AGERE 1.5_ 3.3V)	FX.22500.022
	MODEM BOARD MDC 1.5 FOXCONN T60M951.36 (AGERE 1.5_ 3.3V) AUSTRALIA APPROVED	FX.22500.023
CABLE		
	POWER CORD 3PIN USA	27.AAMVN.001
	POWER CORD 3PIN EUR	27.AAMVN.002
	POWER CORD 3PIN SOUTH AFRICA	27.AAMVN.008
	POWER CORD 3PIN DENMARK	27.AAMVN.010
	POWER CORD ISRAEL	27.AAMVN.011
	POWER CORD 3PIN ITALIAN	27.AAMVN.009
	POWER CORD 3PIN UK	27.AAMVN.004
	POWER CORD 3PIN SWISS	27.AAMVN.006
	POWER CORD AUSTRALIA W/ LABEL	27.AAMVN.003
	POWER CORD 3PIN CHINA	27.AAMVN.005
	POWER CORD SOUTH AFRICA (AIL)	27.AAMVN.007
	POWER CORD 3PIN USA	27.AAMVN.001

	"LCD/CAMERA CABLE 16"" WUXGA/WXGA"	50.APQ0N.012
	"LCD/CAMERA CABLE 16"" WXGA"	50.APQ0N.013
	DC-IN CABLE	50.APQ0N.011
	DC-IN CABLE	50.APD0N.001
	MODEM CABLE WITH RJ11	50.APQ0N.010
	BLUETOOTH BOARD CABLE	50.APQ0N.009
1	FINGER PRINT BOARD CABLE	50.APQ0N.001
	HOTKEY BOARD CABLE	50.APQ0N.002

	POWER BUTTON BOARD CABLE	50.APQ0N.003
The second secon	TOUCH BUTTON BOARD CABLE	50.APQ0N.004
	MEDIA BOARD CABLE	50.APQ0N.005
	E-KEY BOARD CABLE	50.APQ0N.006
N N	USB BOARD CABLE	50.APQ0N.007
The second division in	TOUCHPAD CABLE	50.APQ0N.008
CAMERA		

	CAMERA 0.3M SUYIN	57.APQ0N.001
	CAMERA 0.3M CHICONY	57.APQ0N.002
CASE/COVER/BRACKET ASSEMBLY		
	MINI DUMMY CARD	42.APQ0N.008
	SD DUMMY CARD	42.APQ0N.009
	BD COMBO BEZEL	42.APQ0N.005
	SUPER-MULTI BEZEL	42.APQ0N.004
	"LCD COVER 16"" W/ ANTENNA & MIC"	60.APQ0N.005
	"LCD BEZEL 16"""	60.APQ0N.004
9	LCD BRACKET RIGHT	33.APQ0N.004

BE	LCD BRACKET LEFT	33.APQ0N.005
	UPPER CASE W/ FINGER PRINT HOLE	60.APQ0N.002
	TOUCHPAD BRACKET	33.APQ0N.001
	LOWER CASE	60.APN0N.001
	LOWER CASE	60.APD0N.001
	LOWER CASE	60.AP40N.001
	LOWER CASE	60.APQ0N.001
	MIDDLE COVER	42.APQ0N.001
	UNILOAD COVER	42.APQ0N.002

MPCI COVER	42.APQ0N.003
OPTICAL BRACKET	33.AAMVN.002
KENSINGTON BRACKET	33.APQ0N.006
HINGE COVER ASSEMBLY LEFT	42.APQ0N.007
HINGE COVER ASSEMBLY RIGHT	42.APQ0N.006
TDD	
TBD	TBD

THE REAL PROPERTY OF THE PARTY	VGA BRACKET TOP	33.APQ0N.003
	VGA BRACKET BOTTOM	33.AKE0N.005
CPU/PROCESSOR		
ALTER A	CPU INTEL CORE2DUAL T9500 PGA 2.6G 6M FSB800 PENRYN	KC.95001.DTP
	CPU INTEL CORE2DUAL T9300 PGA 2.5G 6M FSB800 PENRYN	KC.93001.DTP
	CPU INTEL CORE2DUAL T8300 PGA 2.4G 3M FSB800 PENRYN	KC.83001.DTP
	CPU INTEL CORE2DUAL T8100 PGA 2.1G 3M FSB800 PENRYN	KC.81001.DTP
	CPU INTEL CORE2DUAL T7800 PGA 2.6G 4M FSB800	KC.78001.DTP
	CPU INTEL CORE2DUAL T7700 PGA 2.4G 4M FSB800 G-0	KC.77G01.DTP
	CPU INTEL CORE2DUAL T7500 PGA 2.2G 4M FSB800 G-0	KC.75G01.DTP
	CPU INTEL CORE2DUAL T7300 PGA 2.0G 4M FSB800	KC.73001.DTP
	CPU INTEL CORE2DUAL T5750 PGA 2.0G 2M FSB667	KC.57501.DTP
	CPU INTEL CORE2DUAL T5550 PGA 1.83G 2M FSB667	KC.55501.DTP
	CPU INTEL CORE2DUAL T5450 PGA 1.66G 2M FSB667	KC.54501.DTP

	CPU INTEL PENTIUM DUAL- CORE T2370 PGA 1.73G 1M FSB533	KC.23701.DTP
DVD RW DRIVE		
C. S. W. S. C. S. W. S. C. S.	ODD BD COMBO DL 2X SONY BC-5500A LF W/O BEZEL 1.B1 PATA	KO.0020E.001
	ODD BD COMBO DL 2X PANASONIC UJ-120B LF W/O BEZEL PATA	KO.00207.001
	DVD-RW DRIVE 8X SUPER- MULTI TRAY PIONEER DVR- KD08RS LF W/O BEZEL F/ W:1.00 PATA	KU.00805.043
	DVD-RW DRIVE 8X SUPER- MULTI TRAY PANASONIC TRAY UJ-870BAA-A LF W/O BEZEL F/W:1.00 PATA	KU.00807.058
	DVD-RW DRIVE 8X SUPER- MULTI TRAY PHILIPS DS-8A1P LF W/O BEZEL F/W:CA14 PATA	KU.00809.011
	DVD-RW DRIVE 8X SUPER- MULTI TRAY HLDS GSA-T40N LF W/O BEZEL PATA	KU.0080D.030
	DVD-RW DRIVE 8X SUPER- MULTI TRAY SONY AD-7560A LF W/O BEZEL PATA	KU.0080E.005
	DVD-RW DRIVE 8X SUPER- MULTI TRAY TOSHIBA TS- L632H LF W/O BEZEL PATA	KU.00801.020
FAN		
	FAN	23.APQ0N.001
HEATSINK		

	CDULUEATEINIK FOR OCCOM	CO ADDON 000
	CPU HEATSINK FOR 965GM	60.APD0N.002
	CPU HEATSINK FOR 965PM	60.APQ0N.003
	CPU HEATSINK FINGER	33.APD0N.001
	CPU HEATSINK FINGER	33.APQ0N.002
HDD/HARD DISK DRIVER		
The state of the s	HDD 120GB SATA 5400RPM SEAGATE ST9120817AS CORSAIR LF F/W:3.AAA	KH.12001.032
	HDD 120GB 5400RPM SATA TOSHIBA MK1246GSX LEO BS I LF F/W:LB213J	KH.12004.007
	HDD 120GB 5400RPM SATA II HGST HTS542512K9SA00 BRONCO-B LF F/W:C31P	KH.12007.014
	HDD 120GB 5400RPM SATA WD WD1200BEVS-22UST0 ML125 LF F/W:01.01A01	KH.12008.019
	HDD 160GB 5400RPM SATA SEAGATE ST9160827AS CORSAIR LF F/W:3.AAA	KH.16001.029

	HDD 160GB 5400RPM SATA TOSHIBA MK1646GSX LEO BS LF F/W:LB113J	KH.16004.002
	HDD 160GB 5400RPM SATA II HGST HTS542516K9SA00 BRONCO-B LF F/W:C31P	KH.16007.016
	HDD 160GB 5400RPM SATA WD WD1600BEVT-22ZCTO ML160 LF F/W:11.01A11	KH.16008.022
	HDD 160GB 5400RPM SATA SEAGATE ST9250827AS CORSAIR LF F/W:3.AAA	KH.25001.011
	HDD 160GB 5400RPM SATA TOSHIBA MK2546GSX LEO BS LF F/W:LB013J	KH.25004.001
	HDD 250GB 5400RPM SATA II HGST HTS542525K9SA00 LF F/W:C31P	KH.25007.011
	HDD 250GB 5400RPM SATA WD WD2500BEVS-22UST0 ML125 LFF/W:01.01A01	KH.25008.018
	HDD 320GB 5400RPM SATA WD WD3200BEVT-22ZCT0 ML160 LF F/W:11.01A11	KH.32008.013
INVERTER		
The same of the sa	INVERTER BOARD TDK- TBD484NR	19.APQ0N.001
KEYBOARD		
	KEYBOARD 15_16KB-FV1 88KS BLACK US INTERNATIONAL (GLOSSY)	KB.INT00.261
	KEYBOARD 15_16KB-FV1 89KS BLACK TURKISH (GLOSSY)	KB.INT00.264
	KEYBOARD 15_16KB-FV1 88KS BLACK THAILAND (GLOSSY)	KB.INT00.265
	KEYBOARD 15_16KB-FV1 89KS BLACK SWISS/G (GLOSSY)	KB.INT00.266

KEYBOARD 15_16KB-FV1 89KS BLACK SWEDISH (GLOSSY)	KB.INT00.267
KEYBOARD 15_16KB-FV1 89KS BLACK SPANISH (GLOSSY)	KB.INT00.268
KEYBOARD 15_16KB-FV1 89KS BLACK SLOVAK (GLOSSY)	KB.INT00.269
KEYBOARD 15_16KB-FV1 89KS BLACK SLO/CRO (GLOSSY)	KB.INT00.270
KEYBOARD 15_16KB-FV1 88KS BLACK RUSSIAN (GLOSSY)	KB.INT00.271
 KEYBOARD 15_16KB-FV1 89KS BLACK PORTUGUESE (GLOSSY)	KB.INT00.272
KEYBOARD 15_16KB-FV1 89KS BLACK POLISH (GLOSSY)	KB.INT00.273
KEYBOARD 15_16KB-FV1 89KS BLACK NORWEGIAN (GLOSSY)	KB.INT00.274
KEYBOARD 15_16KB-FV1 88KS BLACK KOREAN (GLOSSY)	KB.INT00.276
KEYBOARD 15_16KB-FV1 88KS BLACK JAPANESE (GLOSSY)	KB.INT00.277
KEYBOARD 15_16KB-FV1 89KS BLACK ITALIAN (GLOSSY)	KB.INT00.278
KEYBOARD 15_16KB-FV1 89KS BLACK HUNGARIAN (GLOSSY)	KB.INT00.281
KEYBOARD 15_16KB-FV1 88KS BLACK GREEK (GLOSSY)	KB.INT00.282
KEYBOARD 15_16KB-FV1 89KS BLACK GERMAN (GLOSSY)	KB.INT00.283
KEYBOARD 15_16KB-FV1 89KS BLACK FRENCH (GLOSSY)	KB.INT00.284
KEYBOARD 15_16KB-FV1 89KS BLACK DUTCH (GLOSSY)	KB.INT00.286

KEYBOARD 15_16KB-FV1 89KS BLACK DANISH (GLOSSY) KEYBOARD 15_16KB-FV1 89KS BLACK CZECH (GLOSSY) KEYBOARD 15_16KB-FV1 88KS BLACK TRADITIONAL	KB.INT00.287 KB.INT00.288
89KS BLACK CZECH (GLOSSY) KEYBOARD 15_16KB-FV1	KB.INT00.288
CHINESE (GLOSSY)	KB.INT00.289
KEYBOARD 15_16KB-FV1 89KS BLACK CANADIAN FRENCH (GLOSSY)	KB.INT00.290
KEYBOARD 15_16KB-FV1 89KS BLACK BRAZILIAN PORTUGUESE (GLOSSY)	KB.INT00.291
KEYBOARD 15_16KB-FV1 89KS BLACK BELGIUM (GLOSSY)	KB.INT00.292
KEYBOARD 15_16KB-FV1 88KS BLACK ARABIC/ ENGLISH (GLOSSY)	KB.INT00.293
KEYBOARD 15_16KB-FV1 89KS BLACK ARABIC/ FRENCH (GLOSSY)	KB.INT00.294
KEYBOARD 15_16KB-FV1 89KS BLACK NORDIC (GLOSSY)	KB.INT00.295
KEYBOARD 15_16KB-FV1 89KS BLACK ENGLISH/ CANADIAN FRENCH (GLOSSY)	KB.INT00.296
"LCD 16"" WXGA SAMSUNG LTN160AT01-A01 GLARE LF 220NIT 8MS 600:1 16:9"	LK.16006.001
"LCD 16"" WUXGA SAMSUNG LTN160HT01-A01 GLARE LF 220NIT 8MS 600:1 16:9"	LK.16006.002
SODIMM 512MB DDRII667 NANYA NT512T64UH8B0FN- 3C LF	KN.51203.032
	88KS BLACK TRADITIONAL CHINESE (GLOSSY) KEYBOARD 15_16KB-FV1 89KS BLACK CANADIAN FRENCH (GLOSSY) KEYBOARD 15_16KB-FV1 89KS BLACK BRAZILIAN PORTUGUESE (GLOSSY) KEYBOARD 15_16KB-FV1 89KS BLACK BELGIUM (GLOSSY) KEYBOARD 15_16KB-FV1 89KS BLACK ARABIC/ ENGLISH (GLOSSY) KEYBOARD 15_16KB-FV1 89KS BLACK ARABIC/ FRENCH (GLOSSY) KEYBOARD 15_16KB-FV1 89KS BLACK ARABIC/ FRENCH (GLOSSY) KEYBOARD 15_16KB-FV1 89KS BLACK NORDIC (GLOSSY) KEYBOARD 15_16KB-FV1 89KS BLACK ENGLISH/ CANADIAN FRENCH (GLOSSY) "LCD 16"" WXGA SAMSUNG LTN160AT01-A01 GLARE LF 220NIT 8MS 600:1 16:9" SODIMM 512MB DDRII667 NANYA NT512T64UH8B0FN-

	SODIMM 512MB DDRII667 HYNIX HYMP164S64CP6-Y5 LF	KN.5120G.024
	SODIMM 1GB DDRII667 NANYA NT1GT64U8HB0BN-3C LF	KN.1GB03.014
	SODIMM 1GB DDRII667 HYNIX HYMP112S64CP6-Y5 LF	KN.1GB0G.012
	SODIMM 1GB DDRII667 SAMSUNG M470T2864QZ3- CE6 LF	KN.1GB0B.016
	SODIMM DDRII 667 2GB HYNIX HYMP125S64CP8-Y5 LF	KN.2GB0G.004
	SODIMM DDRII 667 2GB SAMSUNG M470T5663QZ3- CE6 LF	KN.2GB0B.003
MISCELLANEOUS		
•	LCD CHUSION	47.APQ0N.001
	VGA BOARD INSULATOR	47.AKE0N.002
	HDD INSULATOR	42.AAMVN.005
SPEAKER		
	SPEAKER SET W/ SUB- WOOFER	23.APQ0N.002
SCREW		
	SCREW M2.5X0.45	86.APQ0N.001
	SCREW-I25030M (4.0DX0.8T)- BK-PATCH	86.APQ0N.002
	SCREW	86.AAMVN.001
	SCREW BNI PAT	86.TLT0N.002
·		

SCREW I M2 6MM M 4.5MM 0.8MM PHIL BK PATCH	86.APQ0N.004
SCREW I M2.5 2.5MM MACH 4.5MM 0.8MM CROSS BNI	86.APQ0N.005
PATCH	