



Installing iPod Mini Bottom Bezel

Tools used in this guide

- [Small Flathead Screwdriver](#)

Parts relevant to this guide

- [iPod Mini Bottom Bezel](#)



Step 1 - Bottom Bezel

- Carefully insert a small flathead screwdriver in the seam between the metal casing and white plastic bottom. Use the screwdriver to pry up the white plastic bottom bezel. Be careful not to damage the soft plastic with your screwdriver.



Step 2

- Use a flathead screwdriver to pry out the metal retaining bracket beneath the bottom bezel. You can free the bracket by first pushing in the metal arms on the corners and then lifting the bracket.



Step 3

- Lift the metal retaining bracket out of the iPod.