

6. MAIN Electrical Parts List

Design LOC	SEC CODE	Description
D200,D201	0401-001110	DIODE-SWITCHING
ZD200	0403-001547	DIODE-ZENER
D300,D301,D302,D303	0406-001288	DIODE-TVS
D304	0406-001306	DIODE-TVS
ZD304	0406-001322	DIODE-TVS
LED300,LED301,LED302	0601-002674	LED
LED303,LED304,LED305	0601-002674	LED
TR100	1003-001440	IC
UME200	1108-000217	MEMORY
PAM102	1201-002829	IC
U201	1203-005498	IC
U301	1203-005512	IC
U101	1203-005686	IC
U100	1204-002979	IC
UCP200	1205-003679	IC
TH200	1404-001221	THERMISTOR
R304	2007-000139	R-CHIP
R100	2007-000140	R-CHIP
R301,R308,R311,R314	2007-000141	R-CHIP
R104,R105	2007-000143	R-CHIP
C315,R116,R117,R221	2007-000148	R-CHIP
R222	2007-000148	R-CHIP
R118	2007-000151	R-CHIP
R108,R210	2007-000162	R-CHIP
R207,R317,R318,R319	2007-000172	R-CHIP
R320,R321	2007-000172	R-CHIP
R302,R303	2007-000173	R-CHIP
R310	2007-000174	R-CHIP
R211	2007-001301	R-CHIP
R213	2007-001333	R-CHIP
R107	2007-003025	R-CHIP
R212	2007-007698	R-CHIP
R205	2007-008500	R-CHIP
C103	2203-000233	C-CERAMIC,CHIP
C128	2203-000278	C-CERAMIC,CHIP
C227,C231	2203-000425	C-CERAMIC,CHIP
C111,C112	2203-000438	C-CERAMIC,CHIP
C308,C309,C310	2203-000585	C-CERAMIC,CHIP
C303,C305,C306	2203-000679	C-CERAMIC,CHIP
C107,C108,C121,C229	2203-000812	C-CERAMIC,CHIP
C327,C328,C329	2203-000812	C-CERAMIC,CHIP
C325	2203-000995	C-CERAMIC,CHIP
C218,C219,C220,C221	2203-001153	C-CERAMIC,CHIP
C236,C318	2203-001153	C-CERAMIC,CHIP

Design LOC	SEC CODE	Description
C317	2203-001239	C-CERAMIC,CHIP
C223	2203-001405	C-CERAMIC,CHIP
C100,C104,C230,C234	2203-002709	C-CERAMIC,CHIP
C235	2203-002709	C-CERAMIC,CHIP
C129	2203-003054	C-CERAMIC,CHIP
C113,C115	2203-005158	C-CERAMIC,CHIP
C114,C116	2203-005281	C-CERAMIC,CHIP
C105	2203-005288	C-CERAMIC,CHIP
C232,C302,C304,C314	2203-005482	C-CERAMIC,CHIP
C316	2203-005482	C-CERAMIC,CHIP
C120,C203,C204,C216	2203-006048	C-CERAMIC,CHIP
C206,C207	2203-006208	C-CERAMIC,CHIP
C101,C102	2203-006260	C-CERAMIC,CHIP
C224	2203-006348	C-CERAMIC,CHIP
C202,C205,C208,C209	2203-006399	C-CERAMIC,CHIP
C210,C211,C319,C320	2203-006399	C-CERAMIC,CHIP
C109,C311,C312	2203-006562	C-CERAMIC,CHIP
C212,C213	2203-006824	C-CERAMIC,CHIP
C222	2203-006841	C-CERAMIC,CHIP
C228,TA301	2404-001377	C-TA,CHIP
TA101	2404-001381	C-TA,CHIP
TA300	2404-001430	C-TA,CHIP
L306,L307	2703-001723	INDUCTOR-SMD
L103,L110	2703-002198	INDUCTOR-SMD
C110	2703-002200	INDUCTOR-SMD
L104	2703-002204	INDUCTOR-SMD
L106,L107	2703-002208	INDUCTOR-SMD
L100	2703-002269	INDUCTOR-SMD
L105	2703-002281	INDUCTOR-SMD
L308,L309	2703-002309	INDUCTOR-SMD
L310	2703-003064	INDUCTOR-SMD
L201	2703-003297	INDUCTOR-SMD
R101	2203-005552	INDUCTOR-SMD
OSC200	2801-003856	CRYSTAL-UNIT)
OSC201	2801-004552	CRYSTAL-UNIT
F100	2904-001879	FILTER-SAW
L200	3301-001158	CORE-FERRITE BEAD

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.