



11. Disassembly and Assembly Instructions

11-1. Disassembly

1

Place the Touch on the Front



2


Attach the VGA Camera Sponge



1. Place the touch on the front like the picture.

3


Place the LCD module and Assemble TSP FPCB.



1. Attach the VGA Sponge on the position of the picture.

4





Assemble VGA Camera and Bracket.



1. Place the LCD module and Assemble TSP FPCB.


1. Assemble VGA Camera on the Bracket.
2. Assemble the bracket with Front.(Red mark: HOOK point.)

Exploded View and Parts List

<p>5 Assemble KEY FPCB</p>  <p>다</p> 	<p>6 Attach MIC HOLDER and BATT BLACK SHEET</p>  <p>라</p> <p>마</p>
<p>1. Assemble the KEY FPCB with Front using the guide line.</p>	<p>1. Attach Camera SIDE KEY FPCB and assemble MIC HOLDER. 2. Attache Battery BLACK SHEET.</p>
<p>7 Connect Speaker Connector</p>  <p>가</p> <p>나</p>	<p>8 Assemble Speaker</p>  <p>나</p> <p>가</p>
<p>1. Connect the Speaker connector like picture and place the speaker by half turn.</p>	<p>1. Assemble the Antenna wire like picture. 2. Screw Torque: 1.0 ~ 1.2 kgf.cm</p>


9

Assemble KEY FPCB Connector



10

Place the PBA .




1. Connect PBA and KEY FPCB.

1. Place the PBA and connect the VGA Camera connector, LCD connector, 3.5pi Receiver ASS'Y connector, Antenna connector.
 2. Place SUB MIC like picture.


11

Assemble SUB PBA



12

Assemble hold KEY and skew 2 points.




1. Connect SUB PBA and attach SIDE KEY FPCB.

1. Attach HOLD KEY.
 2. Screw 2 points like picture.(Screw Torque: 1.0 ~ 1.2 kgf.cm)


13

Assemble REAR.



14

Screw the 6 points to assemble of REAR.




1. Assemble the REAR using the HOOK point.

1.Screw Torque: 1.0 ~ 1.2 kgf.cm

11-2. Assembly

1 Unscrew 6 points of the Rear.




2 Disassemble the Rear..




1.Unscrew 6 points of the Rear like picture.

1.Disassemble the Rear..

3 Disassemble SUB PBA



4 Disassemble MAIN PBA



1.Unscrew 2 points and Disassemble HOLD KEY and SUB PBA.

1. Detach the connector (VGA,Receiver,LCD, Antenna).
2. Decompose Motor and disassemble PBA.

5

Disassemble Speaker and MIC HOLDER



1.Unscrew and Disassemble Speaker and MIC HOLDER.


6

Detach BATT BLACK SHEET



7

Disassemble KEY PAD




1.Disassemble KEY PAD like the picture.

1.Detach BATT BLACK SHEET

8


Disassemble KEY PBA, MIC HOLDER



1.Disassemble KEY PBA and MIC HOLDER.

9

Disassemble LCD Bracket.



10

Disassemble TSP/LCD .



1. Disassemble LCD Bracket.(Read Mark: HOOK Point)

1. Disassemble TSP/LCD .