


---


# 7. Flow Chart of Troubleshooting


---

## 1. Power On




Power On







## 2. Initial




Initial







### 3. Charging Part




Charging








4. Sim Part




## 5. Microphone Part




Microphone




### 6. Speaker Part(Melody)




Speaker




## 7. Key Data Input



## 8. Receiver Part




## 9. LCD Part







## 10. Key Back Light




### 11. Camera part




## 12. GSM Receiver




### 13. GSM Transmitter




## 14. DCS Receiver



### 15. DCS Transmitter



Transmitter



	VCC/VC_DCS	VCC/VC_PCS	VCC/VC_EGSM
EGSM_TX	1	0	0
EGSM_RX	0	0	0
DCS_TX	0	1	0
DCS_RX	0	0	0
PCS_RX	0	0	1

