



10. Flow Chart of Troubleshooting

10-1 BASEBAND


10-1-1. Power ON





PM IC




10-1-2. Sim Part








10-1-3. Charging Part




CHARGING




10-1-4. Microphone Part - PHONE Mic








MIC_MAIN






10-1-5. Speaker part







10-1-6. Receiver part






10-1-7. Ear mic Part - MIC CABLE







AUDIO_AMP




10-1-8-1. Camera







3M CAM




10-1-8-2. Camera Flash









CAMERA_FLASH




10-1-8-3. Camera zoom & Shutter









10-1-9. Bluetooth




BLUETOOTH / FM RADIO




10-2.RF


10-2-1. EGSM Rx




10-2-2. DCS Rx




10-2-3. PCS Rx




10-2-4. GSM Tx




10-2-5. DCS, PCS Tx




10-2-7. UMTS Rx




10-2-8. UMTS Tx





3G RF



BLUETOOTH / FM RADIO

