





1	9
0	0
0	1
0	1
1	0
1	1




Antenna SW Control Circuit

VC1 : GSM TX VC2 : DCS TX

	VC1	VC2
TX (DCS)	H	L
TX (GSM)	L	H
RX	L	L



DATA1	DATA2	DATA3	DATA4	DATA5	DATA6	DATA7	DATA8	DATA9	DATA10	DATA11	DATA12	DATA13	DATA14	DATA15	DATA16
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>



NC1	NC2	NC3	NC4	NC5	NC6	GROUND	V_BUS	D_P	D_N	SPK_P	SPK_N	WIC_P	WOT_P	NC7	NC8
JT1	JT3	JT2	JT5	JT4	JT6	JT7	JT8	JT9	JT10	JT11	JT12	JT13	JT14	JT15	JT16