





















Antenna S/W Control Circuit
 VC1 : GSM TX VC2 : DCS TX

	VC1	VC2
TX(DCS)	H	L
TX(GSM)	L	H
RX	L	L