



Removing Drum Unit and Toner Cartridge



Step 1 - Drum Unit and Toner Cartridge

- Press the front cover release button.
- Keep the button pressed and pull the cover toward yourself.



Step 2

- With the front cover in the downward position, the drum & toner unit will be visible.
- Grab the black-and-yellow handle on the unit. Lift unit up and pull it out of the printer.

