



Installing HP Photosmart c4780 replacement ink


Tools used in this guide

- [hands](#)
- [replacement ink](#)



Step 1 - replacement ink cartridge install

- Turn on the printer and open up the ink access cover with the handle on the ink access cover



Step 2


- While lightly pushing the top of the ink, it will come out
- be advised there is a key to avoid putting the wrong ink in the wrong slot





Step 3

- Now, with the ink out of the printer, push the ink in straight **WITH THE KEY ON THE INK IN THE RIGHT SIDE** otherwise it wont fit in the slot



Step 4

- calibrate the ink cartridges as shown on the screen (if missing a color, the printer will work)

To reassemble your device, follow these instructions in reverse order.