



Installing IBM ThinkPad 560z Battery

Tools used in this guide

- [Your Hands](#)



Step 1 - Battery

- Slide the button to the right and hold.



Step 2

- Slide the battery out.

