




Disassembling IBM ThinkPad A30 Battery

This guide will show you how to remove the battery for the ThinkPad A30.



Step 1 - Battery

- Place the ThinkPad on its back.
- Slide the highlighted tab to the left.
- With your finger on the tab, remove the battery by lifting it outwards.



To reassemble your device, follow these instructions in reverse order.

This document was last generated on Dec 15, 2010.