



## Disassembling IBM ThinkPad T42 Lower Bracket



### Step 1 - Rear Cover

- Unscrew the following screws on the underside of the T42.
  - Note: for ease of reassembly, keep track of which screws go where.




### Step 2

- Unscrew the 4 screws on either side the rear end of the laptop.



### Step 3 - *installation Keyboard and Trackpad*


- Flip the laptop over and open the display carefully - the keyboard, palm rest and bezel will be loose.



### Step 4

- Maneuver the palm rest away from the keyboard carefully, both the keyboard and palm rest/trackpad will come off together.
- **\*\*WARNING\*\*** Both the keyboard and trackpad have connectors to the motherboard. Disconnect these before completely removing either component.






### Step 5 - Lower Bracket

- The bracket will be free to move.



### Step 6

- Remove the bracket.



### Step 7

- Then remove the small rubber piece covering the small battery.