



Disassembling IBM ThinkPad T42 Rear Cover



Step 1 - Rear Cover

- Unscrew the following screws on the underside of the T42.
 - Note: for ease of reassembly, keep track of which screws go where.



Step 2

- Unscrew the 4 screws on either side the rear end of the laptop.