



Installing IBM ThinkPad T42 Keyboard and Trackpad

Step 1 - disassembly Rear Cover



- Unscrew the following screws on the underside of the T42.
 - Note: for ease of reassembly, keep track of which screws go where.

Step 2


- Unscrew the 4 screws on either side the rear end of the laptop.





Step 3 - Keyboard and Trackpad

- Flip the laptop over and open the display carefully - the keyboard, palm rest and bezel will be loose.



Step 4

- Maneuver the palm rest away from the keyboard carefully, both the keyboard and palm rest/trackpad will come off together.
- ****WARNING**** Both the keyboard and trackpad have connectors to the motherboard. Disconnect these before completely removing either component.

