



Installing Mac mini Model A1347 RAM

Parts relevant to this guide

- [PC3-8500 1 GB RAM Chip](#)
- [PC3-8500 2 GB RAM Chip](#)
- [PC3-8500 4 GB RAM Chip](#)



Step 1 - Bottom Cover

- Place your thumbs in the depressions cut into the bottom cover.
- Rotate the bottom cover counter-clockwise until the white dot painted on the bottom cover is aligned with the ring inscribed on the outer case.



Step 2

- Tilt the mini enough to allow the bottom cover to fall away from the outer case.
- Remove the bottom cover and set it aside.



Step 3 - RAM

- Release the tabs on each side of the RAM chip by simultaneously pushing each tab away from the RAM.
- These tabs lock the chip in place and releasing them will cause the chip to "pop" up.
- After the RAM chip has popped up, pull it straight out of its socket.
- Repeat this process if a second RAM chip is installed.

