



Installing Power Mac G4 M5183 Processor

Tools used in this guide

- [Phillips #1 Screwdriver](#)
- [Phillips #2 Screwdriver](#)
- [Spudger](#)



Step 1 - disassembly Case


- Pull on outer latch.
- Lower door until it is level with your work surface.
- Before working on the computer make sure it is not plugged into a power supply, then touch a metal object. This discharges static electricity, which could damage the computer.






Step 2 - Heat Sink

- Use the spudger to pry the clips horizontally off of the heat sink.
- Fully remove the clips by lifting upwards.



Step 3

- Remove the heat sink by pulling upwards, off of the logic board.



Step 4 - Processor

- Remove the 3 screws attaching the processor to the logic board using the Phillips #2 screwdriver.
- Remove processor by pulling vertically upwards.

