

## FRU Parts Listing

This appendix provides you with the field replaceable unit (FRU) parts listing of the A440 Series. Refer to this appendix whenever ordering for spare parts or requesting for RMA (Returned Merchandise Authorization) number.

<b>FRU</b>	<b>FIC Part Number</b>
<b>Module CD-ROM_24X_TEAC</b>	25-02099-00
CD-ROM 24X - Teac (CD224E)	23-40139-10
CD-ROM BRACKET(L)	24-50749-00
CD-ROM BRACKET(R)	24-50750-00
PLASTIC-M CD-ROM PANEL	80-40173-20
<b>Module - CD-ROM_24X_MKE</b>	25-02069-00
CD-ROM 24X MKE	23-40165-05
CD-ROM BRACKET(L)	24-50749-00
CD-ROM BRACKET(R)	24-50750-00
PLASTIC-M CD-ROM PANEL	80-40308-01
<b>Module - CD-ROM_24X_DELTA</b>	25-02070-00
CD-ROM 24X DELTA	23-40240-00
CD-ROM BRACKET(L)	24-50749-00
CD-ROM BRACKET(R)	24-50750-00
PLASTIC-M CD-ROM PANEL	80-40311-01
<b>Module - DVD-ROM 6X MKE</b>	25-01616-10
DVD-ROM 6X MKE	23-40208-00
CD-ROM BRACKET(L)	24-50990-00
CD-ROM BRACKET(R)	24-50750-00
CD-ROM CYBERLINK POWER DVD SW	24-70110-10
PLASTIC-M DVD-ROM PANEL	80-40181-20
<b>Module - DVD-ROM 6X MKE (W/O POWER)</b>	25-02075-20
DVD-ROM 6X MKE	23-40208-00
CD-ROM BRACKET(L)	24-50990-00
CD-ROM BRACKET(R)	24-50750-00
PLASTIC-M DVD-ROM PANEL	80-40181-20

## FRU Parts Listing

---

<b>Module - DVD-ROM 8X SANYO</b>	25-02072-10
DVD-ROM 8X SANYO	23-40285-00
CD-ROM BRACKET(L)	24-50990-00
CD-ROM BRACKET(R)	24-50750-00
CD-ROM CYBERLINK POWER DVD SW	24-70110-10
PLASTIC-M DVD-ROM PANEL	80-40295-20
<b>Module - DVD-ROM 8X SANYO (W/O POWER)</b>	25-02076-30
DVD-ROM 8X SANYO	23-40285-00
CD-ROM BRACKET(L)	24-50990-00
CD-ROM BRACKET(R)	24-50750-00
PLASTIC-M DVD-ROM PANEL	80-40295-20
<b>Module - DVD-ROM 8X QSI</b>	25-02073-10
DVD-ROM 8X QSI	23-40293-00
CD-ROM BRACKET(L)	24-50990-00
CD-ROM BRACKET(R)	24-50750-00
CD-ROM CYBERLINK POWER DVD SW	24-70110-10
PLASTIC-M DVD-ROM PANEL	80-40312-00
<b>Module - DVD-ROM 8X QSI (W/O POWER)</b>	25-02077-30
DVD-ROM 8X QSI	23-40293-00
CD-ROM BRACKET(L)	24-50990-00
CD-ROM BRACKET(R)	24-50750-00
PLASTIC-M DVD-ROM PANEL	80-40312-00
<b>Module - CD-RW KME</b>	25-02074-10
CD-RW KME	23-40133-01
CD-ROM BRACKET(L)	24-50990-00
CD-ROM BRACKET(R)	24-50750-00
PLASTIC-M DVD-ROM PANEL	80-40291-20
<b>Module HDD _10 GB _HIT</b>	25-02080-10
HDD 10GB HIT	23-20723-00
HDD BRACKET(R)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Module HDD _10 GB _FUJ</b>	25-02080-00
HDD 10GB FUJ	23-20725-00
HDD BRACKET(R)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX

## FRU Parts Listing

---

FRU	FIC Part Number
<b>Module HDD _10 GB _IBM</b>	25-02020-20
HDD 10 GB IBM	23-20725-00
HDD BRACKET(L)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Module HDD _12 GB _HIT</b>	25-02078-10
HDD 12GB HIT	23-20609-02
HDD BRACKET(R)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Module HDD _12 GB _FUJ</b>	25-02078-00
HDD 12GB FUJ	23-20614-00
HDD BRACKET(R)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Module HDD _12 GB _IBM</b>	25-02078-20
HDD 12 GB IBM	23-20620-00
HDD BRACKET(L)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Module HDD _18 GB _HIT</b>	25-02079-10
HDD 18GB HIT	23-20621-00
HDD BRACKET(R)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Module HDD _18 GB _FUJ</b>	25-02079-00
HDD 18GB FUJ	23-20649-00
HDD BRACKET(R)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Module HDD _18 GB _IBM</b>	25-02079-20
HDD 18 GB IBM	23-20622-00
HDD BRACKET(L)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX

## FRU Parts Listing

---

FRU	FIC Part Number
<b>Module HDD _20 GB _HIT</b>	25-02081-10
HDD 20GB HIT	23-20726-00
HDD BRACKET(R)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Module HDD _20 GB _FUJ</b>	25-02081-00
HDD 20GB FUJ	23-20728-00
HDD BRACKET(R)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Module HDD _20 GB _IBM</b>	25-02081-20
HDD 20 GB IBM	23-20741-00
HDD BRACKET(L)	24-50752-10
HDD BRACKET(L)	24-50753-00
HDD Board	51-71069-XX
<b>Battery Pack - NiMH_Panasonic_4500mA:</b>	21-90493-50
<b>Battery Pack LI-ION (PAN) 3200MA</b>	21-91026-50
<b>Dummy Fax Modem</b>	25-02152-00
CASE MODEM JACK COVER	24-44726-00
FAX/MODEM MODULE	71-40156-00
<b>Dummy LAN Module</b>	25-02151-00
CASE MODEM JACK COVER	24-51157-00
LAN/MODEM MODULE	71-40161-00
<b>Main Module</b>	N/A
Charger Board+IO/Bd	51-70588-XX
Charger Board	51-71068-XX
AUDIO Board	51-71088-XX
Main Board	51-71071-XX
BOTTOM CASE Module	80-40320-20
Module TOP Case	80-40167-21
K/B Cover	80-40178-02
MODEM-Cover	80-40163-22
DRAM COVER	80-40254-24

## FRU Parts Listing

FRU	FIC Part Number
<b>Module FDD_Mitsubishi</b>	25-01613-00
FDD 3.5" MITSUBISHI	23-10080-04
F-CABLE FDD FPC	22-20364-21
FDD PLATE	80-50021-20
<b>Module FDD_NEC</b>	25-02012-00
FDD 3.5" NEC	23-10086-05
F-CABLE FDD FPC	22-20364-21
FDD PLATE	80-50021-20
<b>Module Palm Rest</b>	25-02083-00
F-CABLE GLIDE PAD CABLE	22-10406-01
F-CABLE GLIDE PAD FPC	22-21042-00
CASE GLIDE PAD BUTTON	24-44708-20
GLIDE PAD/B	51-71080-21
GLIDE PAD	71-20145-00
PLASTIC-M PALM-REST MODULE	80-40168-22
<b>Module LCD TFT 12.1" LG</b>	56-10231-21
LCD 12.1" TFT LG	71-10532-00
INVERTER/B	12-01295-01
CABLE-M LCD FPC/CABLE 12.1" LG	80-30050-21
LCD BEZEL FOR 12.1"	24-44697-21
LCD COVER FOR 12.1"	80-40214-21
FRAME HINGE-R	24-81923-00
FRAME HINGE-L	24-81924-00
<b>Module LCD TFT 12.1" Sanyo</b>	56-10364-21
LCD 12.1" TFT SANYO	71-10539-01
INVERTER/B	12-01295-01
CABLE-M LCD FPC/CABLE 12.1" SANYO	80-30051-00
LCD BEZEL FOR 12.1"	24-44697-21
LCD COVER FOR 12.1"	80-40214-21
FRAME HINGE-R	24-81923-00
FRAME HINGE-L	24-81924-00
<b>Module LCD DSTN 12.1" PAN</b>	56-10262-21
LCD 12.1" TFT PAN	71-10519-00
INVETER/B	12-01295-01
CABLE-M LCD FPC/CABLE 12.1" PAN	80-30073-10
LCD BEZEL FOR 12.1"	24-44697-21
LCD COVER BACK FOR 12.1"	80-40214-21
FRAME HINGE-R	24-81923-00
FRAME HINGE-L	24-81924-00

## FRU Parts Listing

---

FRU	FIC Part Number
<b>Module LCD TFT 13.3" ADT</b>	56-10236-21
LCD 13.3" TFT ADT	71-10546-00
INVERTER/B	12-01294-01
CABLE-M LCD FPC/CABLE 13.3" ADT	80-30129-00
LCD BEZEL FOR 13.3"	24-44717-21
LCD COVER FOR 13.3"	80-40213-21
FRAME HINGE-R	24-81923-00
FRAME HINGE-L	24-81924-00
<b>Module LCD TFT 14.1" CPT:</b>	56-10367-21
LCD 14.1" TFT CPT	71-10547-00
INVERTER/B	12-01294-01
CABLE-M LCD FPC/CABLE 14.1"CPT	80-30118-00
LCD BEZEL FOR 14.1"	24-44692-21
LCD COVER FOR 14.1"	80-40164-21
FRAME HINGE-R	24-81925-00
FRAME HINGE-L	24-81926-00
<b>AC Adaptor (3 PIN)</b>	12-01322-50
<b>Keyboard (US)</b>	71-30411-00
<b>Keyboard (GER)</b>	71-30411-01
<b>Keyboard (UK)</b>	71-30411-02
<b>Keyboard (JAP)</b>	71-30411-03
<b>Keyboard (SD)</b>	71-30411-04
<b>Keyboard (SPI)</b>	71-30411-05
<b>Keyboard (ITA)</b>	71-30411-06
<b>Keyboard (FRA)</b>	71-30411-07
<b>Keyboard (CHI)</b>	71-30411-08
<b>Keyboard (KOR)</b>	71-30411-09
<b>Keyboard (CZ)</b>	71-30411-10
<b>Keyboard (TURKEY)</b>	71-30411-13
<b>Keyboard (JAP-M)</b>	71-30411-14
<b>Keyboard (PROTUGAL)</b>	71-30411-15
<b>Keyboard (BEL)</b>	71-30411-16
<b>Keyboard (SW/GER)</b>	71-30411-17
<b>Keyboard (SW/FR)</b>	71-30411-18
<b>Keyboard (TURKEY)</b>	71-30411-19
<b>Keyboard (HB)</b>	71-30411-20